ISO 23285:2025-02 (E)

Agricultural machinery, tractors, and earth-moving machinery - Safety of electrical and electronic components and systems operating at 32 V to 75 V DC and 21 V to 50 V AC

Contents

Page

Foreword vi

Introduction vii

1 Scope 1

2 Normative references 1

3 Terms,definitionsandabbreviatedterms 2
3.1 Terms and definitions 2
3.2 Abbreviated terms 8

4 General requirements 9
4.1 V-model 9
4.2 Voltages 9
4.3 Environmental and operational requirements 9
4.4 Components and devices 10

5 Protection against electric shock hazards 10
5.1 Overview 10
5.2 General 10
5.2.1 Fundamental requirements 10
5.2.2 Determination of shock protection requirements 10
5.3 Protective measures 11
5.4 Basic protection 12
5.4.1 General 12
5.4.2 Basic insulation 12
5.4.3 Enclosures or barriers 12
5.4.4 Limitation of touch current or capacitive discharge energy 13
5.4.5 Limitation of voltage 13
5.5 Fault protection 14
5.5.1 General 14
5.5.2 PEPB 15
5.5.3 Automatic disconnection of power supply 20
5.5.4 Supplementary insulation 20
5.5.5 Basic protection between circuits 20
5.6 Enhanced protection 20
5.6.1 General 20
5.6.2 Reinforced insulation and protective separation between circuit 21
5.6.3 Protection by means of protective impedance and limited capacitive discharge energy 21
5.7 Equipment protective combinations 22
5.8 Separation of VC-A2- and VC-B1-systems from VC-B2 (and higher) systems 22
5.9 Protection against residual voltages 23
5.9.1 Basic protection 23
5.9.2 Protection by power supply disruption 23
5.10 Connector human contact 24
5.10.1 General 24
5.10.2 Mated non-enclosed connectors 24
5.10.3 Non-mated, non-enclosed connectors 24

5.10.4 Enclosed connectors 25
5.10.5 Tractor implement plug/socket combinations (or similar mobile machinery implement and attachment combinations) 25
5.11 Water depth 25

6 Wiring practices 26
6.1 Conductor and cable runs 26
6.2 Colour 26
6.3 Cable protection inside an enclosure 26
6.4 Power supply voltage differences 26

7 Overcurrent protection (OCP) 27

7.1 Overview 27
7.2 General 27
7.2.1 Transformers 27
7.2.2 Power converters 27
7.2.3 OCP implementation 27
7.2.4 Rating and setting of OCP 28
7.2.5 Placement of OCP 28
7.2.6 Protection via engine shutoff 28
7.3 Chassis faults/residual currents 28

8 Disconnection and connection 28
8.1 General disconnecting devices 28
8.2 Specifics of disconnecting 28
8.2.1 VC-B1 28
8.2.2 Power converter disconnects 29
8.2.3 Manually actuated disconnecting devices 29
8.2.4 Disconnecting multiple power supplies 30
8.3 Prevention of unintended start-up 30
8.4 Charging power supplies and recuperation 30
8.4.1 Electrical power supplies 30
8.4.2 Powered interchangeable towed machinery and towed machines 31
8.4.3 PTO 31
8.5 Pre-charge protective measures 31

9 Connectors 32
9.1 General 32
9.2 Negative connectors and terminals 32
9.3 Connector mating 32
9.3.1 Incompletely mated connectors 32
9.3.2 Connecting and disconnecting under load 32
9.4 Power cable connections 33
9.5 Terminals for the PEPB cables 33
9.6 Plug/socket combination 33

10 Electric motors and generators 34
10.1 General 34
10.2 Enclosures 34
10.3 Mounting and compartments 35
10.4 Overheating protection 35
10.5 Overspeed protection 35
10.6 Towing and coasting 35
10.7 Bonding 35
10.7.1 Motors and generators 35
10.7.2 Exempted from marking requirement 36

11 Non-motor loads (components) 36
11.1 General 36
11.2 Accessories 36

12 Insulation coordination 36
12.1 General 36
12.2 Cable insulation 37
12.2.1 Temperature and loading 37
12.2.2 Inspection 37
12.2.3 Shielding 37
12.2.4 Different voltages 37

13 Verificationandvalidation 38
13.1 General 38

14 Information for use 38

14.1 General 38
14.2 Markings 38
14.2.1 First responder information 38
14.2.2 Shock hazard symbols 38
14.2.3 Operating voltage 38
14.2.4 Live parts accessible during installation and maintenance 38
14.2.5 Bonding 38
14.2.6 Residual voltage 39
14.2.7 Power supply disruption 39
14.2.8 Disconnected plug/socket combinations 39
14.2.9 Maximum water depth 39
14.2.10 Connection markings 39
14.2.11 Conductor and cable colour markings 39
14.2.12 Bolted joints 39
14.2.13 Disconnection of electrical power supplies 39
14.2.14 Multiple disconnects 40
14.2.15 Unintended start-up 40
14.2.16 External charging 40
14.2.17 Towing 40
14.2.18 Connecting and disconnecting under load 40
14.2.19 Phase cable connections 40
14.2.20 Bonding of motors and generators EPB 40
14.2.21 Shipping, dealer setup and transport 40
14.2.22 Electrical ratings 40
14.2.23 Protection systems 41
14.2.24 General purpose socket-outlets 41
14.2.25 Magnetic hazard symbols 41
14.3 Manuals and technical documentation 41
14.3.1 General 41
14.3.2 Operator's manual 42
14.3.3 Service manuals 43

Annex A (informative)Listofsignificanthazards 45

Annex B (informative) V-Model 46

Annex C (informative) Shock protection requirements 47

Annex D (informative) Protection classes 49

Annex E (informative) Documentation 51

Bibliography 53