

ISO 23285:2025-02 (E)

Agricultural machinery, tractors, and earth-moving machinery - Safety of electrical and electronic components and systems operating at 32 V to 75 V DC and 21 V to 50 V AC

Contents		Page
Foreword		vi
Introduction		vii
1	Scope	1
2	Normative references	1
3	Terms, definitions and abbreviated terms	2
3.1	Terms and definitions	2
3.2	Abbreviated terms	8
4	General requirements	9
4.1	V-model	9
4.2	Voltages	9
4.3	Environmental and operational requirements	9
4.4	Components and devices	10
5	Protection against electric shock hazards	10
5.1	Overview	10
5.2	General	10
5.2.1	Fundamental requirements	10
5.2.2	Determination of shock protection requirements	10
5.3	Protective measures	11
5.4	Basic protection	12
5.4.1	General	12
5.4.2	Basic insulation	12
5.4.3	Enclosures or barriers	12
5.4.4	Limitation of touch current or capacitive discharge energy	13
5.4.5	Limitation of voltage	13
5.5	Fault protection	14
5.5.1	General	14
5.5.2	PEPB	15
5.5.3	Automatic disconnection of power supply	20
5.5.4	Supplementary insulation	20
5.5.5	Basic protection between circuits	20
5.6	Enhanced protection	20
5.6.1	General	20
5.6.2	Reinforced insulation and protective separation between circuit	21
5.6.3	Protection by means of protective impedance and limited capacitive discharge energy	21
5.7	Equipment protective combinations	22
5.8	Separation of VC-A2- and VC-B1-systems from VC-B2 (and higher) systems	22
5.9	Protection against residual voltages	23
5.9.1	Basic protection	23
5.9.2	Protection by power supply disruption	23
5.10	Connector human contact	24
5.10.1	General	24
5.10.2	Mated non-enclosed connectors	24
5.10.3	Non-mated, non-enclosed connectors	24

5.10.4	Enclosed connectors	25
5.10.5	Tractor implement plug/socket combinations (or similar mobile machinery implement and attachment combinations)	25
5.11	Water depth	25
6	Wiring practices	26
6.1	Conductor and cable runs	26
6.2	Colour	26
6.3	Cable protection inside an enclosure	26
6.4	Power supply voltage differences	26
7	Overcurrent protection (OCP)	27
7.1	Overview	27
7.2	General	27
7.2.1	Transformers	27
7.2.2	Power converters	27
7.2.3	OCP implementation	27
7.2.4	Rating and setting of OCP	28
7.2.5	Placement of OCP	28
7.2.6	Protection via engine shutoff	28
7.3	Chassis faults/residual currents	28
8	Disconnection and connection	28
8.1	General disconnecting devices	28
8.2	Specifics of disconnecting	28
8.2.1	VC-B1	28
8.2.2	Power converter disconnects	29
8.2.3	Manually actuated disconnecting devices	29
8.2.4	Disconnecting multiple power supplies	30
8.3	Prevention of unintended start-up	30
8.4	Charging power supplies and recuperation	30
8.4.1	Electrical power supplies	30
8.4.2	Powered interchangeable towed machinery and towed machines	31
8.4.3	PTO	31
8.5	Pre-charge protective measures	31
9	Connectors	32
9.1	General	32
9.2	Negative connectors and terminals	32
9.3	Connector mating	32
9.3.1	Incompletely mated connectors	32
9.3.2	Connecting and disconnecting under load	32
9.4	Power cable connections	33
9.5	Terminals for the PEPB cables	33
9.6	Plug/socket combination	33
10	Electric motors and generators	34
10.1	General	34
10.2	Enclosures	34
10.3	Mounting and compartments	35
10.4	Overheating protection	35
10.5	Overspeed protection	35
10.6	Towing and coasting	35
10.7	Bonding	35
10.7.1	Motors and generators	35
10.7.2	Exempted from marking requirement	36
11	Non-motor loads (components)	36
11.1	General	36
11.2	Accessories	36

12	Insulation coordination	36
12.1	General	36
12.2	Cable insulation	37
12.2.1	Temperature and loading	37
12.2.2	Inspection	37
12.2.3	Shielding	37
12.2.4	Different voltages	37
13	Verification and validation	38
13.1	General	38
14	Information for use	38
14.1	General	38
14.2	Markings	38
14.2.1	First responder information	38
14.2.2	Shock hazard symbols	38
14.2.3	Operating voltage	38
14.2.4	Live parts accessible during installation and maintenance	38
14.2.5	Bonding	38
14.2.6	Residual voltage	39
14.2.7	Power supply disruption	39
14.2.8	Disconnected plug/socket combinations	39
14.2.9	Maximum water depth	39
14.2.10	Connection markings	39
14.2.11	Conductor and cable colour markings	39
14.2.12	Bolted joints	39
14.2.13	Disconnection of electrical power supplies	39
14.2.14	Multiple disconnects	40
14.2.15	Unintended start-up	40
14.2.16	External charging	40
14.2.17	Towing	40
14.2.18	Connecting and disconnecting under load	40
14.2.19	Phase cable connections	40
14.2.20	Bonding of motors and generators EPB	40
14.2.21	Shipping, dealer setup and transport	40
14.2.22	Electrical ratings	40
14.2.23	Protection systems	41
14.2.24	General purpose socket-outlets	41
14.2.25	Magnetic hazard symbols	41
14.3	Manuals and technical documentation	41
14.3.1	General	41
14.3.2	Operator's manual	42
14.3.3	Service manuals	43
	Annex A (informative) List of significant hazards	45
	Annex B (informative) V-Model	46
	Annex C (informative) Shock protection requirements	47
	Annex D (informative) Protection classes	49
	Annex E (informative) Documentation	51
	Bibliography	53