DIN EN 17076:2026-04 (E)

Tower cranes - Anti-collision systems - Safety requirements (includes Amendment :2025)

Contents

Page

European foreword 4

Introduction 5

1 Scope 6

2 Normative references 6

3 Terms and definitions 6

4 List of significant hazards 13

5 Technical requirements 15
5.1 General 15
5.1.1 Components of anti-collision devices and systems 15
5.1.2 Shape of the components of anti-collision devices 15
5.1.3 Requirement for the mechanical installation of the components of anti-collision devices on the crane 16
5.1.4 Crushing or shearing hazards between moving parts 16
5.1.5 Controls 16
5.1.6 Cableless means of communication 16
5.1.7 Safety functions 16
5.1.8 Indicating functions 16
5.1.9 Operating computation 16
5.2 Information requested to operate the anti-collision device and system 17
5.2.1 General 17
5.2.2 Updating time 17
5.2.3 Crane response time 17
5.2.4 Crane status information 17
5.2.5 Crane position information 17
5.2.6 Information to be input manually 19
5.3 Requirements for controls of anti-collision devices 19
5.4 Additional requirements 19

6 Operation of the anti-collision device 19
6.1 Start-up sequence 19
6.2 Normal operation mode of an anti-collision device 19
6.3 Defective status of an anti-collision device 21
6.4 Anti-collision device in a free jib slewing mode 21
6.5 Anti-collision device in overriding mode 21
6.6 Setting mode of an anti-collision device 22
6.7 Communication between anti-collision devices 22
6.8 Indicators at the control station 22
6.9 Outside indicators 22

7 Verification of the safety requirements and/or protective measures 23

8 Marking 24

9 Information for use 24
9.1 General 24

9.2 Instructions for installation 24
9.3 Instructions for setting and functional tests 25
9.4 Instructions for use 25

Annex A (informative) Selection of a suitable set of crane standards for a given application 26

Annex ZA (informative) Relationship between this European Standard and the essential requirements of Directive 2006/42/EC aimed to be covered 28

Bibliography 30