

# ISO 10300-1:2001-08 (E)

## Calculation of load capacity of bevel gears - Part 1: Introduction and general influence factors

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	2
4	Symbols and abbreviations .....	2
5	Application .....	10
6	External force and application factor, $K_A$ .....	13
7	Dynamic factor, $K_v$ .....	15
8	Face load factors, $K_H>$ , $K_F>$ .....	25
9	Transverse load factors, $K_H=$ , $K_F=$ .....	27
Annex A (normative) Calculation of bevel gear geometry .....		34
Annex B (informative) Values for application factor, $K_A$ .....		45
Annex C (informative) Contact patterns .....		46