

ISO 10300-2:2001-08 (E)

Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (pitting)

Contents	Page
Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	2
4 Symbols and abbreviated terms	2
5 Pitting damage-assessment requirements and safety factors	2
6 Gear-tooth rating formulae	3
7 Zone factor, ZH	4
8 Mid-zone factor, ZM-B	5
9 Elasticity factor, ZE	7
10 Load-sharing factor, ZLS	7
11 Spiral-angle factor, Zb	7
12 Bevel gear factor, ZK	8
13 Size factor, ZX	8
14 Lubricant-film influence factors, ZL, Zv, ZR	8
15 Work-hardening factor, ZW	12
16 Life factor, ZNT	13
Annex A (informative) Load sharing factor, ZLS	16