

ISO 10300-2:2001-08 (E)

Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (pitting)

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	2
4	Symbols and abbreviated terms	2
5	Pitting damage-assessment requirements and safety factors	2
6	Gear-tooth rating formulae	3
7	Zone factor, Z_H	4
8	Mid-zone factor, Z_{M-B}	5
9	Elasticity factor, Z_E	7
10	Load-sharing factor, Z_{LS}	7
11	Spiral-angle factor, Z_b	7
12	Bevel gear factor, Z_K	8
13	Size factor, Z_X	8
14	Lubricant-film influence factors, Z_L , Z_v , Z_R	8
15	Work-hardening factor, Z_W	12
16	Life factor, Z_{NT}	13
Annex A (informative)	Load sharing factor, Z_{LS}	16