

ISO 10300-2:2001-08 (E)

Calculation of load capacity of bevel gears - Part 2: Calculation of surface durability (pitting)

Contents		Page
Foreword		iv
Introduction		v
1 Scope		1
2 Normative references		1
3 Terms and definitions		2
4 Symbols and abbreviated terms		2
5 Pitting damage-assessment requirements and safety factors		2
6 Gear-tooth rating formulae		3
7 Zone factor, Z_H		4
8 Mid-zone factor, Z_{M-B}		5
9 Elasticity factor, Z_E		7
10 Load-sharing factor, Z_{LS}		7
11 Spiral-angle factor, Z_b		7
12 Bevel gear factor, Z_K		8
13 Size factor, Z_X		8
14 Lubricant-film influence factors, Z_L , Z_v , Z_R		8
15 Work-hardening factor, Z_W		12
16 Life factor, Z_{NT}		13
Annex A (informative) Load sharing factor, Z_{LS}		16