

# DIN EN 474-11:2007-09 (E)

## Earth-moving machinery - Safety - Part 11: Requirements for earth and landfill compactors

---

<b>Contents</b>	<b>Page</b>
Foreword .....	3
Introduction .....	4
1 <b>Scope</b> .....	5
2 <b>Normative references</b> .....	5
3 <b>Terms and definitions</b> .....	5
4 <b>List of additional significant hazards</b> .....	6
5 <b>Safety requirements and/or measures</b> .....	6
6 <b>Information for use</b> .....	8
<b>Annex A (normative) List of additional significant hazards - Earth and landfill compactors</b> .....	9
<b>Annex B (informative) Illustrations</b> .....	10
<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/EC</b> .....	11
<b>Bibliography</b> .....	12
<b>Figures Figure B.1 -- Earth and landfill compactors with loading equipment</b> .....	10
<b>Figure B.2 -- Earth and landfill compactors with dozing equipment</b> .....	10
<b>Tables Table A.1 -- List of additional significant hazards</b> .....	9