

# DIN EN 12387:2006-04 (E)

## Footwear, leather and imitation leather goods manufacturing machines - Modular shoe repair equipment - Safety requirements

---

<b>Contents</b>	<b>Page</b>
Foreword .....	3
1 <b>Scope</b> .....	5
2 <b>Normative references</b> .....	6
3 <b>Terms and definitions</b> .....	7
4 <b>List of hazards</b> .....	8
5 <b>Safety requirements and/or measures</b> .....	16
6 <b>Verification of safety requirements and/or measures</b> .....	20
7 <b>Information for use</b> .....	23
<b>Annex A (normative) Requirements for covers and guards</b> .....	26
<b>Annex B (normative) Requirements for hold-to-run control device for combined heel and sole presses</b> .....	27
<b>Annex C (normative) Noise test code for modular shoe repair equipment</b> .....	28
<b>Annex D (normative) Requirements for dust extraction system</b> .....	31
<b>Annex E (normative) Minimum distances and working height for finishing machines</b> .....	32
<b>Annex F (normative)</b> .....	33
<b>Annex G (informative) Lighting for finishing machines</b> .....	35
<b>Bibliography</b> .....	37