

# ISO 6336-6:2006-08 (E)

## Calculation of load capacity of spur and helical gears - Part 6: Calculation of service life under variable load

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b> .....		<b>iv</b>
<b>1</b>	<b>Scope</b> .....	<b>1</b>
<b>2</b>	<b>Normative references</b> .....	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols and abbreviated terms</b> .....	<b>1</b>
<b>4</b>	<b>General</b> .....	<b>1</b>
<b>4.1</b>	<b>Application factors</b> .....	<b>1</b>
<b>4.2</b>	<b>Determination of load and stress spectra</b> .....	<b>1</b>
<b>4.3</b>	<b>General calculation of service life</b> .....	<b>4</b>
<b>4.4</b>	<b>Palmgren-Miner rule</b> .....	<b>5</b>
<b>5.1</b>	<b>Basic principles</b> .....	<b>5</b>
<b>5.2</b>	<b>Calculation of stress spectra</b> .....	<b>7</b>
<b>5.3</b>	<b>Determination of pitting and bending strength values</b> .....	<b>8</b>
<b>5.4</b>	<b>Determination of safety factors</b> .....	<b>8</b>
<b>Annex A (normative) Determination of application factor, <math>K_A</math>, from given load spectrum using equivalent torque, <math>T_{eq}</math></b> .....		<b>10</b>
<b>Annex B (informative) Guide values for application factor, <math>K_A</math></b> .....		<b>15</b>
<b>Annex C (informative) Example calculation of safety factor from given load spectrum</b> .....		<b>18</b>
<b>Bibliography</b> .....		<b>24</b>