

# ISO 6336-2:2006-09 (E)

## Calculation of load capacity of spur and helical gears - Part 2: Calculation of surface durability (pitting)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms, definitions, symbols and abbreviated terms .....	2
4	Pitting damage and safety factors .....	2
5	Basic formulæ .....	3
5.1	General .....	3
5.2	Safety factor for surface durability (against pitting), SH .....	3
5.3	Contact stress, H .....	3
5.4	Permissible contact stress, HP .....	5
6	Zone factor, ZH, and single pair tooth contact factors, ZB and ZD .....	9
6.1	Zone factor, ZH .....	9
6.2	Single pair tooth contact factors, ZB and ZD, for $u \leq 2$ .....	10
6.3	Single pair tooth contact factors, ZB and ZD, for $u > 2$ .....	11
7	Elasticity factor, ZE .....	11
8	Contact ratio factor, Z .....	12
8.1	Determination of contact ratio factor, Z .....	13
8.2	Calculation of transverse contact ratio, $\epsilon_H$ , and overlap ratio, $\epsilon_{\alpha}$ .....	14
9	Helix angle factor, Z $\beta$ .....	15
10	Strength for contact stress .....	16
10.1	Allowable stress numbers (contact), H lim, for Method B .....	16
10.2	Allowable stress number values for Method BR .....	16
11	Life factor, ZNT (for flanks) .....	16
11.1	Life factor ZNT: Method A .....	17
11.2	Life factor ZNT: Method B .....	17
12	Influence of lubricant film, factors ZL, Z $v$ and ZR .....	18
12.1	General .....	18
12.2	Influence of lubricant film: Method A .....	19
12.3	Influence of lubricant film, factors ZL, Z $v$ and ZR: Method B .....	19
13	Work hardening factor, ZW .....	24
13.1	Work hardening factor, ZW: Method A .....	24
13.2	Work hardening factor, ZW: Method B .....	25
14	Size factor, ZX .....	29
Annex A (informative)	Start of involute .....	30
Bibliography .....		33