

# ISO/TR 25398:2006-10 (E)

Earth-moving machinery - Guidelines for assessment of exposure to whole-body vibration of ride-on machines - Use of harmonized data measured by international institutes, organizations and manufacturers

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1 <b>Scope</b> .....		1
2 <b>Normative references</b> .....		1
3 <b>Terms and definitions</b> .....		2
4 <b>Estimation of vibration magnitude</b> .....		5
5 <b>Estimation of daily exposure duration</b> .....		5
6 <b>Consideration of uncertainties</b> .....		6
7 <b>Determination and assessment of vibration exposure</b> .....		7
8 <b>Documentation</b> .....		16
<b>Annex A (informative) Machine types and their typical operating conditions</b> .....		17
<b>Annex B (informative) Equivalent vibration values of whole-body vibration emission of earth-moving machinery</b> .....		21
<b>Annex C (informative) Calculation form for total vibration exposure points</b> .....		23
<b>Annex D (informative) Example documentation form for whole-body vibration exposure</b> .....		24
<b>Annex E (informative) Guidelines for use and working conditions of earth-moving machinery to reduce vibration levels</b> .....		25
<b>Annex F (informative) Guidelines for establishing and reporting vibration reduction of earth-moving machinery</b> .....		27
<b>Bibliography</b> .....		28