

DIN ISO 11088:2018-10 (E)

Alpine ski/binding/boot (S-B-B) system - Assembly, adjustment and inspection (ISO 11088:2018)

Contents

| | Page |
|---|------|
| National foreword | 3 |
| National Annex NA (informative) Bibliography | 4 |
| Foreword | 5 |
| Introduction | 6 |
| 1 Scope | 7 |
| 2 Normative references | 7 |
| 3 Terms and definitions | 7 |
| 4 Principle | 9 |
| 5 Skier's parameters | 9 |
| 5.1 General..... | 9 |
| 5.2 Weight method..... | 9 |
| 6 Equipment parameters | 9 |
| 6.1 Choice of new equipment..... | 9 |
| 6.2 Visual inspection and preparation of used equipment..... | 9 |
| 6.3 Assembly..... | 10 |
| 6.4 Binding-to-boot fitting adjustments..... | 10 |
| 6.5 Initial indicator adjustment..... | 10 |
| 6.6 Functional check (inspection of functions)..... | 10 |
| 6.7 Measurement of release moment..... | 10 |
| 6.8 Report..... | 11 |
| Annex A (normative) Definition of skier type | 12 |
| Annex B (normative) Method of setting | 14 |
| Annex C (normative) Flow chart | 16 |
| Annex D (normative) Clean versus lubricated diagnostic test for boot/binding compatibility | 18 |
| Annex E (informative) Drill | 19 |
| Bibliography | 20 |