

DIN EN 13922:2011-11 (E)

Tanks for transport of dangerous goods - Service equipment for tanks - Overfill prevention systems for liquid fuels

Contents		Page
Foreword		4
Introduction		5
1	Scope	6
2	Normative references	6
3	Terms and definitions	6
4	Functions	8
5	Major components	8
5.1	Vehicle mounted equipment	8
5.2	Equipment fitted at the gantry	9
6	Characteristics	9
6.1	Overfill prevention system working characteristics	9
6.1.1	Overfill	9
6.1.2	Bonding	9
6.1.3	Severe environmental condition	9
6.2	Sensors	9
6.2.1	General	9
6.2.2	NTC thermistor, two-wire optic or other compatible sensor	10
6.2.3	A five-wire optic or compatible sensor	10
6.2.4	Sensor circuit	10
6.2.5	Response time	10
6.2.6	Materials of construction	10
6.2.7	Electrical requirements	10
6.3	Overfill prevention controller characteristics	11
6.3.1	Interface	11
6.3.2	Outputs	11
6.3.3	Response time	11
6.3.4	Status indicators	11
6.3.5	Materials of construction	11
6.3.6	Temperature range	11
6.3.7	Electrical requirements	11
6.4	Cable and plug interface characteristics	12
6.4.1	Plug	12
6.4.2	Cable	12
6.4.3	Temperature range	12
7	Testing	12
7.1	General	12
7.2	Type tests	12
7.2.1	General	12
7.2.2	Performance tests	13
7.2.3	Electromagnetic compatibility (EMC) test	13
7.2.4	Fail safe testing	13
7.3	Production tests	13

8	Marking	13
9	Installation, operation and maintenance instructions	13
	Annex A (normative) Electrical specifications	14
A.1	Electrical specifications	14
A.2	Functional tests	18
	Bibliography	32