

# ISO 12090-2:2011-08 (E)

## Rolling bearings - Profiled rail guides for linear motion rolling bearings - Part 2: Boundary dimensions and tolerances for series 4 and 5

---

| <b>Contents</b>   |   | <b>Page</b> |
|---|---|-------------|
| <b>Foreword</b> .....   |   | <b>iv</b>   |
| <b>1</b>  | <b>Scope</b> .....                      | <b>1</b>    |
| <b>2</b>  | <b>Normative references</b> .....       | <b>1</b>    |
| <b>3</b>  | <b>Terms and definitions</b> .....      | <b>1</b>    |
| <b>4</b>  | <b>Symbols</b> .....                    | <b>4</b>    |
| <b>5</b>  | <b>Design types</b> .....               | <b>5</b>    |
| <b>6</b>  | <b>Boundary dimensions</b> .....        | <b>5</b>    |
| <b>6.1</b>  | <b>Profiled rail guides</b> .....       | <b>5</b>    |
| <b>6.2</b>  | <b>Multi-piece profiled rails</b> ..... | <b>8</b>    |
| <b>7</b>  | <b>Tolerances</b> .....                 | <b>8</b>    |
| <b>Annex A (informative) General length tolerances for profiled rails</b> ..... |   | <b>10</b>   |