ISO 3547-5:2020-05 (E)

Plain bearings - Wrapped bushes - Part 5: Checking the outside diameter

Contents

Page

Foreword ..... **iv**

Introduction ..... **v**

1 Scope **1**

2 Normative references **1**

3 Terms and definitions **1**

4 Symbols and units **1**

5 Outside diameter, D_o **2**

6 Purpose of checking **2**

7 Methods of checking **2**
7.1 General 2
7.2 Checking method A — Measurement of outside diameter, D_o 3
7.3 Checking method B — Gauging of outside diameter, D_o 3
7.4 Checking method D — Measurement of outside diameter, D_o > 120 mm 3

8 Selection of checking method for outside diameter **3**

9 ISO 3547-2:2017, test A — Outside diameter, Do **3**
9.1 Measuring equipment 3
9.2 Requirements for checking the block and the setting plug 5
9.3 Determination of correction factor, C 10
9.4 Procedure 10
9.5 Measuring errors 11
9.5.1 General 11
9.5.2 Errors due to measuring equipment 11
9.5.3 Errors due to the bush 11
9.5.4 Errors due to human factors 11
9.6 Summary of the factors relating to the measurement of the outside diameter, D_o, of the bush 11
9.6.1 Checking load, F_{ch} 11
9.6.2 Diameter of the checking block, $d_{ch,1}$, and of the setting plug, $d_{ch,2}$ 11
9.6.3 Upper limiting value and lower limiting value for Δz 11
9.6.4 Correction factor, C 12
9.6.5 Conversion of the indicated measured value, Δz, for outside diameter 12

10 ISO 3547-2:2017, test B — Outside diameter, Do **12**
10.1 Gauging equipment 12
10.2 Requirements for measuring equipment 12
10.3 Procedure 13
10.4 Measuring errors 13

11 ISO 3547-2, test D — Outside diameter, Do > 120 mm **13**
11.1 Gauging equipment 13
11.2 Measuring equipment 13
11.3 Procedure 14
11.4 Measuring errors 14

12 Specifications on drawings of bushes **14**

13 Specifications for control of the checking equipment **14**
13.1 Gauging equipment 14
13.2 Measuring equipment 14

Bibliography **15**