

DIN EN 13856:2026-08 (E)

LPG equipment and accessories - Minimum requirements for the content of the user manual for automotive LPG systems

Contents	Page
European foreword	3
Introduction	4
1 Scope	5
2 Normative references	5
3 Terms and definitions	5
4 General	5
5 of the user manual	5
5.1 LPG system description	5
5.2 Safety instructions	6
5.3 Operation of the LPG system	6
5.3.1 Filling of the LPG container	6
5.3.2 Switch-over procedure	6
5.3.3 Opening / closing of manual valves when fitted	6
5.3.4 Level indicator	6
5.4 Maintenance	6
5.5 Defects and repair	6
Bibliography	7