

# ISO/TS 22762-4:2014-07 (E)

## Elastomeric seismic-protection isolators - Part 4: Guidance on the application of ISO 22762-3

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Guidance on the use of Clause 4 of ISO 22762-3 .....</b>	<b>1</b>
<b>5</b>	<b>Guidance on the use of Clause 5 of ISO 22762-3 .....</b>	<b>1</b>
<b>6</b>	<b>Guidance on the use of Clause 6 of ISO 22762-3 .....</b>	<b>1</b>
<b>6.1</b>	<b>General .....</b>	<b>1</b>
<b>6.2</b>	<b>Type tests and routine tests .....</b>	<b>1</b>
<b>6.3</b>	<b>Functional requirements .....</b>	<b>3</b>
<b>6.4</b>	<b>Design compressive force and design shear displacement .....</b>	<b>3</b>
<b>6.5</b>	<b>Performance requirements .....</b>	<b>4</b>
<b>7</b>	<b>Guidance on the use of Clause 7 of ISO 22762-3 .....</b>	<b>24</b>
<b>7.1</b>	<b>General .....</b>	<b>24</b>
<b>7.2</b>	<b>Compressive stiffness .....</b>	<b>24</b>
<b>8</b>	<b>Guidance on the use of Clause 8 of ISO 22762-3 .....</b>	<b>31</b>
<b>9</b>	<b>Guidance on the use of Clause 9 of ISO 22762-3 .....</b>	<b>31</b>
<b>10</b>	<b>Guidance on the use of Clause 10 of ISO 22762-3 .....</b>	<b>31</b>
<b>11</b>	<b>Guidance on the use of Clause 11 of ISO 22762-3 .....</b>	<b>31</b>