

# ISO 4250-2:2023-04 (E)

## Earth-mover tyres and rims - Part 2: Loads and inflation pressures

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>3.1</b>	<b>Masses .....</b>	<b>1</b>
<b>3.2</b>	<b>Operating conditions .....</b>	<b>2</b>
<b>4</b>	<b>Special conditions .....</b>	<b>3</b>
<b>5</b>	<b>Selection of tyres for new machine design .....</b>	<b>3</b>
<b>6</b>	<b>Inflation pressures .....</b>	<b>4</b>
<b>7</b>	<b>Load/inflation tables .....</b>	<b>4</b>
<b>8</b>	<b>Load capacities for earth-mover tyres used for industrial service .....</b>	<b>5</b>
<b>Bibliography .....</b>		<b>27</b>