

# DIN EN 15241:2011-06 (E)

## Ventilation for buildings - Calculation methods for energy losses due to ventilation and infiltration in buildings (includ es Corrigendum AC:2011)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
1	Scope .....	6
2	Normative references .....	6
3	Terms and definitions .....	6
4	Symbols and abbreviations .....	7
5	General approach .....	8
6	Steady state calculation .....	9
6.1	Basis of the calculation method .....	9
6.2	Air entering through infiltration, passive air inlets or windows .....	9
6.3	Air entering through balanced or supply only system calculation .....	9
6.3.1	General .....	9
6.3.2	Duct heat losses .....	10
6.3.3	Duct flow losses .....	10
6.3.4	Fan .....	10
6.3.5	heat exchanger .....	13
6.3.6	Mixing boxes .....	15
6.3.7	Pre-heating .....	16
6.3.8	Pre-cooling .....	16
6.3.9	Humidifying in winter .....	17
6.3.10	Dehumidification .....	17
7	Implementation of the method .....	18
7.1	General .....	18
7.2	Hourly method .....	18
7.3	Monthly methods .....	19
7.3.1	System with no or low humidity impact .....	19
7.3.2	System with medium or high humidity impact .....	19
7.4	Statistical approach to be applied at national level .....	20
Annex A (informative)	A simplified model of a Ground to Air Heat Exchanger .....	21
A.1	Background and summary .....	21
A.2	Overview of program links, variables, parameters and constants .....	22
A.3	Physical description of the ground to air heat x-change model .....	23
Bibliography .....		26