

# ISO 52031:2020-04 (E)

## Energy performance of buildings - Method for calculation of system energy requirements and system efficiencies - Space emission systems (heating and cooling)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Symbols and subscripts .....</b>	<b>2</b>
<b>4.1</b>	<b>Symbols .....</b>	<b>2</b>
<b>4.2</b>	<b>Subscripts .....</b>	<b>2</b>
<b>5</b>	<b>Description of the method .....</b>	<b>2</b>
<b>5.1</b>	<b>Output of the method .....</b>	<b>2</b>
<b>5.2</b>	<b>General description of the method .....</b>	<b>3</b>
<b>6</b>	<b>Calculation method .....</b>	<b>3</b>
<b>6.1</b>	<b>Output data .....</b>	<b>3</b>
<b>6.2</b>	<b>Calculation time interval .....</b>	<b>3</b>
<b>6.3</b>	<b>Input data .....</b>	<b>4</b>
<b>6.3.1</b>	<b>Source of data .....</b>	<b>4</b>
<b>6.3.2</b>	<b>Product data (technical data) .....</b>	<b>4</b>
<b>6.3.3</b>	<b>Configuration and system design data .....</b>	<b>5</b>
<b>6.3.4</b>	<b>Operating or boundary conditions .....</b>	<b>5</b>
<b>6.4</b>	<b>Calculation procedure .....</b>	<b>6</b>
<b>6.4.1</b>	<b>Applicable calculation interval .....</b>	<b>6</b>
<b>6.4.2</b>	<b>Energy calculation (additional heating/cooling losses) .....</b>	<b>6</b>
<b>6.4.3</b>	<b>Auxiliary energy calculation .....</b>	<b>10</b>
<b>Annex A (normative)</b>	<b>Template for choices, input data and references (additional heating and cooling losses/auxiliary energy) .....</b>	<b>12</b>
<b>Annex B (informative)</b>	<b>Default choices, input data and references (additional heating and cooling losses/auxiliary energy) .....</b>	<b>26</b>
<b>Annex C (informative)</b>	<b>Boundary conditions for the development of energy related input parameter</b>	<b>40</b>
<b>Bibliography .....</b>		<b>46</b>