

# DIN EN 13757-4:2026-02 (E)

## Communication systems for meters - Part 4: Wireless M-Bus communication

---

<b>Contents</b>		<b>Page</b>
European foreword .....		6
Introduction .....		7
1	Scope .....	9
2	Normative references .....	9
3	Terms and definitions .....	9
4	Symbols and abbreviated terms .....	11
4.1	Symbols .....	11
4.2	Abbreviated terms .....	11
5	General .....	12
5.1	Modes of operation .....	12
5.2	Meter communication types .....	13
5.3	Performance classes .....	15
6	Mode S .....	16
6.1	Channel properties .....	16
6.2	Transmitter .....	17
6.3	Receiver .....	18
6.4	Data encoding and preamble .....	18
6.4.1	Data encoding .....	18
6.4.2	Order of transmission of the encoded data .....	18
6.4.3	Preamble and synchronization pattern .....	18
7	Mode T .....	19
7.1	Channel properties .....	19
7.2	Transmitter .....	19
7.3	Receiver .....	20
7.4	Data encoding and preamble .....	21
7.4.1	General .....	21
7.4.2	Meter transmit, "3 out of 6" data encoding .....	21
7.4.3	Other Device transmit, Manchester encoding .....	23
8	Mode R2 .....	23
8.1	Channel properties .....	23
8.2	Transmitter .....	23
8.3	Receiver .....	25
8.4	Data encoding and preamble .....	25
8.4.1	Data encoding .....	25
8.4.2	Order of transmission of the encoded data .....	25
8.4.3	Preamble and synchronization pattern .....	25
9	Mode C .....	26
9.1	Channel properties .....	26
9.2	Transmitter .....	26
9.3	Receiver .....	27
9.4	Data encoding and preamble .....	28
9.4.1	Encoding .....	28

9.4.2	Preamble and synchronization pattern .....	28
10	Mode N .....	28
10.1	Channel properties .....	28
10.2	Physical link parameters .....	30
10.3	Receiver sensitivity .....	32
10.4	Data encoding and preamble .....	32
10.4.1	Encoding .....	32
10.4.2	Preamble and synchronization pattern .....	33
11	Mode F .....	33
11.1	Channel properties .....	33
11.2	Physical link parameters .....	33
11.3	Receiver sensitivity .....	34
11.4	Data encoding and preamble .....	35
11.4.1	Data Encoding .....	35
11.4.2	Preamble and synchronization pattern .....	35
12	Data Link Layer .....	35
12.1	General .....	35
12.2	Order of multi byte fields .....	35
12.3	Frame format A .....	36
12.4	Frame format B .....	36
12.5	Field definitions .....	37
12.5.1	General .....	37
12.5.2	Multi byte fields .....	37
12.5.3	Length field (L-Field) .....	37
12.5.4	Control field (C-Field) .....	37
12.5.5	Manufacturer ID (M-field) .....	39
12.5.6	Address (A-field) .....	39
12.5.7	Cyclic redundancy check (CRC-field) .....	40
12.5.8	Control information field (CI-field) .....	40
12.6	Timing .....	40
12.6.1	Timing for installation messages .....	40
12.6.2	Synchronous transmissions of meter messages .....	41
12.6.3	Access timing .....	43
12.7	Repeated or duplicate messages .....	44
12.8	Forward error correction (FEC) .....	44
12.8.1	Overview .....	44
12.8.2	Datagram structure .....	44
12.8.3	FEC Algorithm .....	45
13	Connection to higher protocol layers .....	46
13.1	The Control information field (CI-field) .....	46
13.2	CI-fields for the Extended Link Layer .....	48
13.2.1	General .....	48
13.2.2	CI-field = 8Ch .....	48
13.2.3	CI-field = 8Dh .....	48
13.2.4	CI-field = 8Eh .....	49
13.2.5	CI-field = 8Fh .....	49
13.2.6	CI-field = 86h .....	49
13.2.7	Communication Control Field (CC-field) .....	50
13.2.8	Access Number Field (ACC-field) .....	52
13.2.9	Manufacturer ID 2 (M2-field) .....	52
13.2.10	Address 2 (A2-field) .....	52
13.2.11	Session Number Field (SN-field) .....	52
13.2.12	AES-128 Counter Mode Encryption .....	53
13.2.13	Run Time Delay field (RTD-field) .....	54
13.2.14	Reception Level field (RXL-field) .....	55
13.2.15	Payload Checksum Field (PayloadCRC-field) .....	56
13.3	CI-fields for the Transport Layer .....	57
13.3.1	General .....	57

13.3.2	Short Transport Layer .....	57
13.3.3	Long Transport Layer .....	57
14	Management functions for link control .....	57
14.1	General .....	57
14.2	Set Radio Parameters .....	61
14.2.1	General .....	61
14.2.2	Command .....	61
14.2.3	Response .....	64
14.3	Get Radio Parameters .....	67
14.3.1	General .....	67
14.3.2	Command .....	67
14.3.3	Response .....	67
14.4	Set limited radio parameters .....	69
14.4.1	General .....	69
14.4.2	Command .....	69
14.4.3	Response .....	71
14.5	Confirm Radio Parameters .....	71
14.5.1	General .....	71
14.5.2	Command .....	71
14.5.3	Response .....	72
14.6	Set manufacturer specific parameters .....	73
14.6.1	General .....	73
14.6.2	Command .....	73
14.6.3	Response .....	74
Annex A (informative) Frequency allocation and transmit power for the 868 MHz band .....		75
Annex B (informative) Frequency allocation for the 169 MHz band .....		76
B.1	Frequencies and allowed power levels .....	76
B.2	Frequencies and corresponding maximum duty cycles .....	76
Annex C (informative) Frame examples .....		78
C.1	Example of a frame from a meter in mode S .....	78
C.1.1	Conditions .....	78
C.1.2	Block content .....	78
C.1.3	Bit string .....	79
C.2	Example of a frame from a meter in mode T1 .....	79
C.2.1	Condition .....	79
C.2.2	Block Content .....	80
C.2.3	Bit string .....	80
C.3	Example of a frame from a meter in mode C1 .....	81
C.3.1	Conditions .....	81
C.3.2	Block content .....	81
C.3.3	Bit string .....	82
Annex D (informative) Example of predictive reception of synchronous messages .....		83
Annex E (informative) Timing diagrams .....		84
Annex F (informative) Counter Mode Flow .....		103
Bibliography .....		104