

ISO/IEC 11572:2000-03 (E)

Information technology — Telecommunications and information exchange between systems — Private Integrated Services Network — Circuit mode bearer services — Inter-exchange signalling procedures and protocol

Contents	Page
Foreword	vii
Introduction	viii
1 Scope	1
2 Conformance	1
3 Normative references	1
4 Terms and definitions	1
5 List of acronyms	3
6 General principles	3
6.1 Protocol model	4
6.2 Services provided to Call Control	4
6.3 Services required of the Signalling Carriage Mechanism	5
7 Protocol Control states	5
7.1 States for circuit-mode Call Control	5
7.1.1 Null State (0)	5
7.1.2 Call Initiated (1)	5
7.1.3 Overlap Sending (2)	5
7.1.4 Outgoing Call Proceeding (3)	5
7.1.5 Call Delivered (4)	5
7.1.6 Call Present (6)	5
7.1.7 Call Received (7)	5
7.1.8 Connect Request (8)	5
7.1.9 Incoming Call Proceeding (9)	6
7.1.10 Active (10)	6
7.1.11 Disconnect Request (11)	6
7.1.12 Disconnect Indication (12)	6
7.1.13 Release Request (19)	6
7.1.14 Overlap Receiving (25)	6
7.2 States for layer management	6
7.2.1 Null State (Rest 0)	6
7.2.2 Restart Request (Rest 1)	6
7.2.3 Restart (Rest 2)	6
8 Call Control	6
8.1 States for Transit PINX Call Control	7
8.1.1 TCC_Idle (0)	7
8.1.2 TCC_Await Digits (1)	7
8.1.3 TCC_Await Additional Digits (2)	7
8.1.4 TCC_Overlap (3)	7
8.1.5 TCC_Incoming Call Proceeding (4)	7
8.1.6 TCC_Transit Call Proceeding (5)	7
8.1.7 TCC_Call Alerting (6)	7
8.1.8 TCC_Call Active (7)	7
8.1.9 TCC_Await Incoming Release (8)	7
8.1.10 TCC_Await Outgoing Release (9)	7
8.1.11 TCC_Await Two-Way Release (10)	7
8.1.12 TCC_Await Incoming Disconnect (11)	7

8.1.13	TCC_Await Outgoing Disconnect (12)	7
8.1.14	TCC_Await Two-Way Disconnect (13)	8
9	General procedures	8
9.1	Use of the services of Signalling Carriage Mechanism	8
9.1.1	Establishment of a Signalling Carriage Mechanism connection	8
9.1.2	Transfer of data	8
9.1.3	Signalling Carriage Mechanism reset	8
9.1.4	Signalling Carriage Mechanism failure	8
9.2	Handling of protocol error conditions	8
9.2.1	Protocol discriminator error	8
9.2.2	Message too short	8
9.2.3	Call reference error	8
9.2.4	Message type or message sequence errors	9
9.2.5	General information element errors	9
9.2.6	Mandatory information element errors	10
9.2.7	Non-mandatory information element errors	10
9.2.8	Signalling Carriage Mechanism reset	11
9.2.9	Signalling Carriage Mechanism failure	11
9.3	Status and status enquiry protocol procedures	12
9.3.1	Status enquiry procedure	12
9.3.2	Receiving a STATUS message	12
10	Circuit-switched Call Control procedures	14
10.1	Call establishment	14
10.1.1	Call request	14
10.1.2	Information channel selection	15
10.1.3	Overlap sending	15
10.1.4	Call proceeding	16
10.1.5	Call confirmation indication	17
10.1.6	Call connected	17
10.1.7	Use of the PROGRESS message	17
10.1.8	Failure of call establishment	18
10.2	Call clearing	18
10.2.1	Terminology	18
10.2.2	Exception conditions	18
10.2.3	Clearing	19
10.2.4	Clear collision	19
10.3	Call collisions	19
10.4	Transit PINX Call Control requirements	19
10.4.1	Receipt of address information	20
10.4.2	State TCC_Await_Digits	20
10.4.3	State TCC_Await_Additional_Digits	21
10.4.4	State TCC_Overlap	22
10.4.5	Channel through connection procedures	22
10.4.6	State TCC_Incoming_Call_Proceeding	23
10.4.7	State TCC_Transit_Call_Proceeding	23
10.4.8	State TCC_Call_Alerting	24
10.4.9	State TCC_Call_Active	24
10.4.10	Call clearing at a Transit PINX	24
10.4.11	Handling of Basic Call information elements at a Transit PINX	25

10.5	Originating PINX Call Control requirements	26
10.5.1	Transmission of the SETUP message	26
10.5.2	Agreement of the information channel	27
10.5.3	Receipt of Progress indicators	27
10.5.4	Receipt of ALERTING message	27
10.5.5	Receipt of CONNECT message	27
10.5.6	Call clearing initiated by the Originating PINX	27
10.5.7	Receipt of an indication of call clearing	27
10.6	Terminating PINX Call Control requirements	28
10.6.1	Receipt of the SETUP message	28
10.6.2	Transmission of ALERTING message	28
10.6.3	Transmission of Progress indicators	28
10.6.4	Transmission of CONNECT message	28
10.6.5	Call clearing initiated by the Terminating PINX	29
10.6.6	Receipt of an indication of call clearing	29
10.7	Incoming Gateway PINX Call Control requirements	29
10.7.1	Transmission of the SETUP message	29
10.7.2	Interworking indications in the SETUP Message	30
10.7.3	Agreement of the information channel	30
10.7.4	Receipt of Progress indicators	30
10.7.5	Receipt of ALERTING message	30
10.7.6	Receipt of CONNECT message	30
10.7.7	Call clearing initiated by the Incoming Gateway PINX	31
10.7.8	Receipt of an indication of call clearing	31
10.8	Outgoing Gateway PINX Call Control requirements	31
10.8.1	Receipt of the SETUP message	31
10.8.2	Connection of the information channel	32
10.8.3	Transmission of interworking indications	32
10.8.4	Transmission of ALERTING message	32
10.8.5	Transmission of CONNECT message	32
10.8.6	Call clearing initiated by the Outgoing Gateway PINX	33
10.8.7	Receipt of an indication of call clearing	33
11	Procedures for layer management	33
11.1	Restart procedures	33
11.1.1	Sending RESTART	33
11.1.2	Receipt of RESTART	34
11.1.3	Restart collision	34
12	Protocol timers	35
13	Functional definition of messages	36
13.1	Messages for general procedures	37
13.1.1	STATUS	37
13.1.2	STATUS ENQUIRY	37
13.2	Messages for Circuit Mode Call Control	38
13.2.1	ALERTING	38
13.2.2	CALL PROCEEDING	38
13.2.3	CONNECT	38
13.2.4	CONNECT ACKNOWLEDGE	39
13.2.5	DISCONNECT	39
13.2.6	INFORMATION	39
13.2.7	PROGRESS	39
13.2.8	RELEASE	40
13.2.9	RELEASE COMPLETE	40

13.2.10	SETUP	40
13.2.11	SETUP ACKNOWLEDGE	41
13.3	Messages for layer management	41
13.3.1	RESTART	41
13.3.2	RESTART ACKNOWLEDGE	41
14	General message format and coding of information elements	41
14.1	Overview	42
14.2	Protocol discriminator	42
14.3	Call reference	43
14.4	Message type	44
14.5	Other information elements for Basic Call control (codeset 0)	44
14.5.1	Coding rules	44
14.5.2	Extension of codesets	46
14.5.3	Locking shift procedure	47
14.5.4	Non-locking shift procedure	47
14.5.5	Bearer capability	48
14.5.6	Call state	50
14.5.7	Called party number	51
14.5.8	Called party subaddress	52
14.5.9	Calling party number	53
14.5.10	Calling party subaddress	53
14.5.11	Cause	54
14.5.12	Channel identification	57
14.5.13	Connected number	60
14.5.14	Connected subaddress	60
14.5.15	High layer compatibility (layers 4-7)	61
14.5.16	Low layer compatibility (layers 1-3)	61
14.5.17	Progress indicator	61
14.5.18	Restart indicator	62
14.5.19	Sending complete	63
14.6	Information elements of codeset 5	63
Annex A	(normative) Protocol Implementation Conformance Statement (PICS) for ISO/IEC 11572	64
Annex B	(informative) Use of the cause information element	75
Annex C	(informative) Examples of message sequences	78
Annex D	(informative) Manufacturer specific information	82
Annex E	(informative) SDL diagram for the procedures over a symmetrical link between two peer PINX's	83
Annex F	(informative) SDL diagram for the procedures on either side of a Transit-PINX	104
Annex G	(informative) Bibliography	120
Annex ZA	(normative) Segmentation and reassembly procedures	121
Annex ZB	(normative) Additional progress descriptions	131
Annex ZC	(normative) Party category functionality	135