

DIN EN 13525:2010-05 (E)

Forestry machinery - Wood chippers - Safety (includes Amendment A2:2009)

Contents

Page

Foreword.....	4
0 Introduction	5
1 Scope	6
2 Normative references	7
3 Terms and definitions	8
4 Safety requirements and/or measures	10
4.1 General.....	10
4.2 Operator controls.....	10
4.2.1 General.....	10
4.2.2 Starting the machine	10
4.2.3 Stopping the machine	11
4.2.4 Infeed stop control.....	11
4.2.5 Safety and reliability of control systems.....	15
4.3 Protection against mechanical hazards	16
4.3.1 Stability	16
4.3.2 Risk of break-up during operation	16
4.3.3 Hazards related to infeed components and chipping components	17
4.3.4 Risks due to ejected objects	19
4.3.5 Protection against access to moving power transmission parts	19
4.4 Protection against non-mechanical hazards	20
4.4.1 Noise	20
4.4.2 Hydraulic components	21
4.4.3 Hot surfaces	21
4.4.4 Electrical hazards	21
4.5 Preparation for transport and maintenance.....	22
5 Verification of the safety requirements and/or measures	23
5.1 General.....	23
5.2 Stability	23
5.3 Chipping components risk of break-up.....	24
5.4 Hot surfaces	24
5.4.1 Temperature measuring equipment.....	24
5.4.2 Test method.....	24
5.4.3 Test acceptance	25
5.5 Verification of requirements on noise – Measurement of noise emission	25
6 Information for use	25
6.1 Instruction handbook	25
6.2 Marking	27
6.3 Warnings.....	27
Annex A (normative) List of significant hazards	30
Annex B (normative) Noise test code - Engineering method (grade 2)	34
Annex C (normative)  Machines with integrated feed chain conveyor 	38
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 98/37/EC, amended by Directive 98/79/EC	41
Annex ZB (informative)  Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC 	42
Bibliography.....	43