

# DIN EN 16486:2014-10 (E)

## Machines for compacting waste materials or recyclable fractions - Compactors - Safety requirements

---

<b>Contents</b>		<b>Page</b>
Foreword .....		4
Introduction .....		5
1	Scope .....	6
2	Normative references .....	7
3	Terms and definitions .....	9
4	List of significant hazards .....	13
5	Safety requirements and/or protective measures .....	16
5.1	Mechanical hazards .....	16
5.1.1	General .....	16
5.1.2	Feed equipment area .....	18
5.1.3	Feed hopper/opening area and compaction chamber .....	19
5.1.4	Area behind the compacting parts .....	22
5.1.5	Container closing devices .....	22
5.1.6	Interface between compaction unit and container on static compactors .....	23
5.1.7	Emptying process of transportable compactors .....	23
5.1.8	Handling of transportable compactors .....	23
5.1.9	Traversing systems .....	24
5.2	Hazards due to failures in the control system or unexpected start-up .....	27
5.2.1	Control devices, actuators and systems .....	27
5.2.2	Prevention of unauthorised operation .....	27
5.2.3	Emergency stop .....	27
5.2.4	Required performance levels PLr .....	27
5.3	Electrical hazards .....	28
5.4	Hazards from hydraulic equipment .....	28
5.5	Slips, trips and falls .....	29
5.6	Hazards generated by noise .....	29
5.6.1	Noise reduction at source by design .....	29
5.6.2	Noise reduction by protective measures .....	29
5.6.3	Information connected with noise hazards .....	29
5.7	Hazards due to neglecting ergonomic principles in the design of the machine .....	29
6	Verification of the safety requirements and/ or protective measures .....	29
7	Information for use .....	32
7.1	General Information .....	32
7.2	Information for safe operation .....	32
7.2.1	General .....	32
7.2.2	Instructions for operation .....	33
7.2.3	Information on noise .....	33
7.2.4	Installation instructions .....	34
7.2.5	Setting and maintenance instructions .....	34
7.2.6	Spare parts list .....	35
7.2.7	Preventing faults and fault recovery .....	35
7.2.8	Information for preventing and removing blockages .....	35

7.2.9	Information relating to connections between the compactor, container and any traversing systems .....	35
7.2.10	Transportable compactors .....	35
7.2.11	Information on examinations and/or inspections .....	36
7.3	Marking .....	37
7.3.1	Manufacturer's plate .....	37
7.3.2	Safety signs .....	37
Annex A (normative) Noise test code .....		39
A.1	Scope .....	39
A.2	Determination of emission sound pressure level at the work station(s) .....	39
A.2.1	Basic standards .....	39
A.2.2	Measurement uncertainty .....	40
A.3	Determination of sound power levels .....	40
A.3.1	Basic standards .....	40
A.3.2	Measurement uncertainty .....	40
A.4	Installation and mounting conditions for the noise measurement .....	41
A.5	Operating conditions .....	41
A.6	Information to be recorded and reported .....	41
A.6.1	General .....	41
A.6.2	Compactor data .....	41
A.6.3	Standards used .....	41
A.6.4	Noise data .....	41
A.6.5	Installation and operating conditions .....	41
A.7	Declaration and verification of noise emission values .....	41
Annex B (informative) Preliminary dialogue between manufacturer and user .....		43
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC .....		44
Bibliography .....		45