ISO 18202:2015-12 (E)

Space data and information transfer systems - Mission operations message abstraction layer

Contents

Page

1 INTRODUCTION **1-1**

1.1 GENERAL 1-1
1.2 PURPOSE AND SCOPE 1-1
1.3 DOCUMENT STRUCTURE 1-1
1.4 DEFINITION OF TERMS 1-2
1.5 NOMENCLATURE 1-4
1.6 REFERENCES 1-4

2 OVERVIEW **2-1**

2.1 GENERAL 2-1
2.2 ABSTRACT INTERFACE SPECIFICATIONS 2-1
2.3 ABSTRACT SERVICE SPECIFICATIONS 2-8

3 ABSTRACT SERVICE SPECIFICATIONS **3-1**

3.1 OVERVIEW 3-1
3.2 TRANSACTION HANDLING 3-1
3.3 STATE TRANSITIONS 3-1
3.4 MESSAGE COMPOSITION 3-2
3.5 MAL SERVICE INTERFACE 3-4
3.6 ACCESS CONTROL INTERFACE 3-100
3.7 TRANSPORT INTERFACE 3-104

4 MAL DATA TYPE SPECIFICATION **4-1**

4.1 OVERVIEW 4-1
4.2 FUNDAMENTALS 4-8
4.3 ATTRIBUTES 4-9
4.4 DATA STRUCTURES 4-14

5 MAL ERRORS **5-1**

6 SERVICE SPECIFICATION XML **6-1**

7 CONFORMANCE MATRIX **7-1**

ANNEX A SECURITY, SANA AND PATENT CONSIDERATIONS (NORMATIVE) **A-1**
ANNEX B DEFINITION OF ACRONYMS (INFORMATIVE) **B-1**
ANNEX C INFORMATIVE REFERENCES (INFORMATIVE) **C-1**

Figure Page

2-1 Message Exchange Sequence Example 2-2
2-2 Request, Indication, and Message Relationship 2-4
2-3 Consumer State Diagram Example 2-5
2-4 Message Decomposition Key 2-7
2-5 Message Header Decomposition Example 2-7
2-6 Message Body Decomposition Example 2-7
3-1 SEND Interaction Pattern Message Sequence 3-4
3-2 SUBMIT Interaction Pattern Message Sequence 3-8
3-3 SUBMIT Interaction Pattern Error Sequence 3-9
3-4 SUBMIT Consumer State Chart 3-10
3-5 SUBMIT Provider State Chart 3-11
3-6 REQUEST Interaction Pattern Message Sequence 3-16
3-7 REQUEST Interaction Pattern Error Sequence 3-17
3-8 REQUEST Consumer State Chart 3-18
3-9 REQUEST Provider State Chart 3-19
3-10 INVOKE Interaction Pattern Message Sequence 3-24
3-11 INVOKE Interaction Pattern Error Sequence 3-25
3-12 INVOKE Consumer State Chart 3-27
3-13 INVOKE Provider State Chart 3-28
3-14 PROGRESS Interaction Pattern Message Sequence 3-36
3-15 PROGRESS Interaction Pattern Error Sequence 3-37
3-16 PROGRESS Consumer State Chart 3-39
3-17 PROGRESS Provider State Chart 3-41
3-18 PUBLISH-SUBSCRIBE Interaction Pattern Message Sequence 3-53
3-19 PUBLISH-SUBSCRIBE Pattern Alternative Message Sequence 3-54
3-20 PUBLISH-SUBSCRIBE Interaction Pattern Consumer Error Sequence 3-59
3-21 PUBLISH-SUBSCRIBE Interaction Pattern Provider Error Sequence 3-60
3-22 PUBLISH-SUBSCRIBE Consumer State Chart 3-67
3-23 PUBLISH-SUBSCRIBE Broker to Consumer State Chart 3-70
3-24 PUBLISH-SUBSCRIBE Provider State Chart 3-72
3-25 PUBLISH-SUBSCRIBE Broker to Provider State Chart 3-74
3-26 CHECK Access Control Pattern Message Sequence 3-100
3-27 CHECK Access Control Pattern Error Sequence 3-101
3-28 SUPPORTEDQOS Transport Pattern Message Sequence 3-105
3-29 SUPPORTEDIP Transport Pattern Message Sequence 3-108
3-30 TRANSMIT Transport Pattern Message Sequence 3-111
3-31 TRANSMIT Transport Pattern Error Sequence 3-112
3-32 TRANSMITMULTIPLE Transport Pattern Message Sequence 3-115
3-33 TRANSMITMULTIPLE Transport Pattern Error Sequence 3-116
3-34 RECEIVE Transport Pattern Message Sequence 3-119
3-35 RECEIVEMULTIPLE Transport Pattern Message Sequence 3-122

Table Page

2-1 Example Operation Template 2-3
2-2 Example Primitive List 2-4
2-3 Service Overview Table 2-8
3-1 MAL Message Header Fields 3-3
3-2 SEND Operation Template 3-5
3-3 SEND Primitive List 3-5
3-4 SEND Message Header Fields 3-7
3-5 SUBMIT Operation Template 3-9
3-6 SUBMIT Primitive List 3-10
3-7 SUBMIT Message Header Fields 3-13
3-8 Submit ACK Message Header Fields 3-14
3-9 REQUEST Operation Template 3-17
3-10 REQUEST Primitive List 3-18
3-11 REQUEST Message Header Fields 3-21
3-12 Request RESPONSE Message Header Fields 3-22
3-13 INVOKE Operation Template 3-26
3-14 INVOKE Primitive List 3-26
3-15 INVOKE Message Header Fields 3-30
3-16 Invoke ACK Message Header Fields 3-31
3-17 Invoke RESPONSE Message Header Fields 3-33
3-18 PROGRESS Operation Template 3-38
3-19 PROGRESS Primitive List 3-38
3-20 PROGRESS Message Header Fields 3-44
3-21 Progress ACK Message Header Fields 3-45
3-22 Progress UPDATE Message Header Fields 3-47
3-23 Progress RESPONSE Message Header Fields 3-50
3-24 PUBLISH-SUBSCRIBE Operation Template 3-61
3-25 PUBLISH-SUBSCRIBE Register Operation Template 3-61
3-26 PUBLISH-SUBSCRIBE Publish Register Operation Template 3-62
3-27 PUBLISH-SUBSCRIBE Publish Operation Template 3-62
3-28 PUBLISH-SUBSCRIBE Publish Error Operation Template 3-62
3-29 PUBLISH-SUBSCRIBE Notify Operation Template 3-62
3-30 PUBLISH-SUBSCRIBE Notify Error Operation Template 3-63
3-31 PUBLISH-SUBSCRIBE Deregister Operation Template 3-63
3-32 PUBLISH-SUBSCRIBE Publish Deregister Operation Template 3-63
3-33 PUBLISH-SUBSCRIBE Primitive List 3-66
3-34 REGISTER Message Header Fields 3-77
3-35 REGISTER_ACK Message Header Fields 3-78
3-36 PUBLISH_REGISTER Message Header Fields 3-81
3-37 PUBLISH_REGISTER_ACK Message Header Fields 3-82
3-38 PUBLISH Message Header Fields 3-86

Table Page

3-39 PUBLISH_ERROR Message Header Fields 3-87
3-40 NOTIFY Message Header Fields 3-89
3-41 DEREGISTER Message Header Fields 3-92
3-42 DEREGISTER_ACK Message Header Fields 3-94
3-43 PUBLISH_DEREGISTER Message Header Fields 3-95
3-44 PUBLISH_DEREGISTER_ACK Message Header Fields 3-97
3-45 CHECK Operation Template 3-101
3-46 CHECK Primitive List 3-102
3-47 SUPPORTEDQOS Operation Template 3-106
3-48 SUPPORTEDQOS Primitive List 3-106
3-49 SUPPORTEDIP Operation Template 3-109
3-50 SUPPORTEDIP Primitive List 3-109
3-51 TRANSMIT Operation Template 3-112
3-52 TRANSMIT Primitive List 3-113
3-53 TRANSMITMULTIPLE Operation Template 3-116
3-54 TRANSMITMULTIPLE Primitive List 3-117
3-55 RECEIVE Operation Template 3-120
3-56 RECEIVE Primitive List 3-120
3-57 RECEIVEMULTIPLE Operation Template 3-123
3-58 RECEIVEMULTIPLE Primitive List 3-123
5-1 Standard MAL Error Codes 5-1
7-1 Conformance Matrix 7-1