

# ISO 9667:2016-01 (E)

## Aircraft ground support equipment - Tow bars

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Aircraft mass categories .....</b>	<b>1</b>
<b>4</b>	<b>Tow bar general requirements .....</b>	<b>2</b>
<b>5</b>	<b>Aircraft connection .....</b>	<b>2</b>
<b>5.1</b>	<b>Dimension of tow bar connection to aircraft .....</b>	<b>2</b>
<b>5.2</b>	<b>Aircraft interface requirements .....</b>	<b>2</b>
<b>5.3</b>	<b>Aircraft protective provisions .....</b>	<b>2</b>
<b>5.3.1</b>	<b>General requirements .....</b>	<b>2</b>
<b>5.3.2</b>	<b>Shear pins .....</b>	<b>3</b>
<b>5.3.3</b>	<b>Marking .....</b>	<b>4</b>
<b>6</b>	<b>Tractor connection .....</b>	<b>4</b>
<b>7</b>	<b>Tow bar undercarriage .....</b>	<b>5</b>