ISO 20683-1:2016-08 (E)

Aircraft ground equipment - Nose gear towbarless towing vehicle (TLTV) - Design, testing and maintenance requirements - Par t 1: Main line aircraft

Contents

Page

Foreword v

Introduction vi

1 Scope 1

2 Normative references 1

3 Termsanddefinitions 2

4 Design requirements 4
4.1 General 4
4.2 Towing loads 4
4.3 Pick-up and holding system 5
4.4 Oversteering protection 5
4.5 Nose wheels retention 6
4.6 Safety 6
4.6.1 General 6
4.6.2 Pick-up, release and associated loads 6
4.6.3 Acceleration, deceleration and associated loads 6
4.6.4 Emergency braking 7
4.6.5 Oversteer limits 7
4.6.6 Oversteer alerting and/or protection 7
4.7 Testing operations 8
4.7.1 Snubbing and jerking 8
4.7.2 Vibrations 8
4.7.3 Aircraft braking 8
4.7.4 Stability 8
4.8 Nose gear steering angle limit 9
4.9 Vehicle classification 9
4.10 Placarding 9

5 Testing requirements 9
5.1 General 9
5.2 Testing objectives 9
5.3 Aircraft configuration 10
5.4 Calibration 10
5.4.1 General 10
5.4.2 Aircraft calibration 10
5.4.3 TLTV calibration 13
5.4.4 Oversteering calibration 14
5.5 Testing procedures 14
5.5.1 General 14
5.5.2 Data recording 14

6 Evaluation 15
6.1 Evaluation criteria 15
6.2 Normal condition testing 15
6.2.1 Testing methods 15
6.2.2 Tests number 15
6.2.3 Pushback 15

6.2.4 Maintenance towing 16
6.2.5 Pick-up and release 16
6.2.6 Test evaluation 16
6.3 Stability testing 17
6.4 Extreme condition testing 17
6.4.1 Testing methods 17
6.4.2 Static load tests 17
6.4.3 Maximum acceleration and braking 17

6.5 Oversteer testing 18

7 Maintenance 18
7.1 General 18
7.2 Maintenance manual 19
7.3 Requirements 19
7.4 Calibration 20
7.5 Special tools 20
7.6 Training 20
7.7 Maintenance records 20

8 Quality control 21

9 Traceability and accountability 22

10 Modifications 22

11 Operating instructions 23

Bibliography 24