

# DIN EN 16604-10:2020-04 (E)

Space sustainability - Part 10: Space debris mitigation requirements (ISO 24113:2011, modified); English version EN 16604-10:2019

---

<b>Contents</b>	<b>Page</b>
<b>European foreword</b> .....	<b>3</b>
<b>Introduction</b> .....	<b>4</b>
<b>1 Scope</b> .....	<b>5</b>
<b>2 Normative references</b> .....	<b>5</b>
<b>3 Terms and definitions</b> .....	<b>5</b>
<b>4 Symbols and abbreviated terms</b> .....	<b>7</b>
<b>4.1 Symbols</b> .....	<b>7</b>
<b>4.2 Abbreviated terms</b> .....	<b>7</b>
<b>5 Protected regions</b> .....	<b>8</b>
<b>5.1 General</b> .....	<b>8</b>
<b>5.2 LEO protected region</b> .....	<b>8</b>
<b>5.3 GEO protected region</b> .....	<b>8</b>
<b>6 Technical requirements</b> .....	<b>9</b>
<b>6.1 Avoiding the intentional release of space debris into Earth orbit during normal operations</b> .....	<b>9</b>
<b>6.1.1 General</b> .....	<b>9</b>
<b>6.1.2 Combustion-related products</b> .....	<b>9</b>
<b>6.2 Avoiding break-ups in Earth orbit</b> .....	<b>9</b>
<b>6.2.1 Intentional break-ups</b> .....	<b>9</b>
<b>6.2.2 Accidental break-ups</b> .....	<b>9</b>
<b>6.3 Removing a spacecraft or launch vehicle orbital stage from the protected regions after end of mission</b> .....	<b>10</b>
<b>6.3.1 Probability of successful disposal</b> .....	<b>10</b>
<b>6.3.2 GEO disposal manoeuvres</b> .....	<b>10</b>
<b>6.3.3 LEO disposal manoeuvres</b> .....	<b>10</b>
<b>6.3.4 Re-entry</b> .....	<b>11</b>
<b>7 Space debris mitigation plan</b> .....	<b>11</b>
<b>Annex A (informative) Probability of successful disposal</b> .....	<b>12</b>
<b>A.1 General</b> .....	<b>12</b>
<b>A.2 Case 1</b> .....	<b>12</b>
<b>A.3 Case 2</b> .....	<b>13</b>
<b>A.4 Case 3</b> .....	<b>13</b>
<b>Annex B (informative) Post-launch life cycle phases of a launch vehicle or spacecraft</b> .....	<b>15</b>
<b>Bibliography</b> .....	<b>17</b>