

# ISO 16049-2:2020-01 (E)

## Air cargo equipment - Restraint straps - Part 2: Utilization requirements and recommendations and lashing calculations

---

| <b>Contents</b>    |  | <b>Page</b> |
|--------------------|--|-------------|
| Foreword .....     |  | iv          |
| Introduction ..... |  | v           |
| <b>1</b>           | <b>Scope .....</b>                       | <b>1</b>    |
| <b>2</b>           | <b>Normative references .....</b>        | <b>1</b>    |
| <b>3</b>           | <b>Terms and definitions .....</b>       | <b>2</b>    |
| <b>4</b>           | <b>General requirements .....</b>        | <b>4</b>    |
| <b>5</b>           | <b>Tie-down method .....</b>             | <b>8</b>    |
|                    | 5.1 Basic method .....                   | 8           |
|                    | 5.2 Directions of restraint .....        | 8           |
| <b>6</b>           | <b>Calculation methods .....</b>         | <b>9</b>    |
|                    | 6.1 Load factors .....                   | 9           |
|                    | 6.2 Calculation principles .....         | 10          |
|                    | 6.3 Practical calculation .....          | 11          |
|                    | 6.4 Calculation sheet .....              | 11          |
| <b>7</b>           | <b>Specific requirements .....</b>       | <b>12</b>   |
|                    | 7.1 General .....                        | 12          |
|                    | 7.2 Risk of cargo slippage .....         | 13          |
|                    | 7.3 Risk of cargo tilting .....          | 13          |
|                    | 7.4 Long and narrow items .....          | 13          |
| <b>8</b>           | <b>Operator's responsibilities .....</b> | <b>14</b>   |
|                    | <b>Bibliography .....</b>                | <b>16</b>   |