

ISO 16412:2005-05 (E)

Air cargo equipment - Air cargo pallets - Utilization guidelines

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	2
4	General requirements	3
4.1	General	3
4.2	Mass	3
4.3	Area load	4
4.4	Running load	4
4.5	CG location (plan view)	4
4.6	CG location (height)	5
4.7	Contour	6
5	Installation	6
5.1	Condition check	6
5.2	Cargo stacking	7
5.3	Shifting protection	9
5.4	Net installation	9
6	Shoring	10
6.1	General	10
6.2	Methods	11
6.3	Computation	12
7	Restraint	13
7.1	Net restraint	13
7.2	Straps complement	13
7.3	Straps tie-down	14
8	Specific commodities	14
8.1	General	14
8.2	Overhangs	14
8.3	Long loads	15
8.4	"Tall" loads	16
8.5	Drums, cans, barrels	16
8.6	Reels, spools	16
8.7	Dangerous goods	17
9	Pallet accessories	18
9.1	Pallet covers	18
9.2	Pallet extenders	19
9.3	Pallet couplings	19
9.4	Other accessories	19
10	Operator requirements	20
10.1	General	20
10.2	Operating instructions	20
10.3	Training and qualification	21
10.4	Quality control	21
Bibliography		22