

# DIN EN 12312-15:2006-03 (E)

## Aircraft ground support equipment - Specific requirements - Part 15: Baggage and equipment tractors

---

<b>Contents</b>		<b>Page</b>
page Foreword .....		3
Introduction .....		4
1	Scope .....	5
2	Normative references .....	5
3	Terms and definitions .....	6
4	List of significant hazards .....	6
5	Safety requirements and/or measures .....	6
5.1	General requirements .....	6
5.2	Driver's accommodation .....	7
5.3	Driver's cabin .....	7
5.4	Seats .....	8
5.5	Controls, monitoring devices and displays .....	8
5.6	Additional operating positions .....	8
5.7	Chassis and body .....	9
5.8	Electrical equipment .....	9
6	Information for use .....	9
6.1	Marking .....	9
6.2	Additional marking .....	9
6.3	Instructions .....	10
7	Verification of requirements .....	10
Annex A (informative) Examples of typical baggage and equipment tractors .....		11
Annex B (normative) List of hazards in addition to those of EN 1915-1 .....		12
Annex C (normative) Minimum space envelope for seated operator enclosure .....		14
Annex D (informative) Examples of couplings .....		15
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive Machinery Directive 98/37/EC .....		17
Bibliography .....		18