

# ISO 23794:2010-02 (E)

## Rubber, vulcanized or thermoplastic - Abrasion testing - Guidance

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Wear mechanisms .....</b>	<b>2</b>
<b>5</b>	<b>Types of abrasion test .....</b>	<b>3</b>
<b>6</b>	<b>Abradants .....</b>	<b>4</b>
<b>7</b>	<b>Test conditions .....</b>	<b>4</b>
7.1	Temperature .....	4
7.2	Degree and rate of slip .....	5
7.3	Contact pressure .....	5
7.4	Continuous/intermittent contact .....	5
7.5	Lubricants and contamination .....	5
<b>8</b>	<b>Abrasion test apparatus .....</b>	<b>5</b>
<b>9</b>	<b>Reference materials .....</b>	<b>7</b>
<b>10</b>	<b>Test procedure .....</b>	<b>8</b>
<b>11</b>	<b>Expression of results .....</b>	<b>12</b>
<b>Bibliography .....</b>		<b>14</b>