

# ISO 23794:2023-01 (E)

## Rubber, vulcanized or thermoplastic - Abrasion testing - Guidance

---

<b>Contents</b>		<b>Page</b>
Foreword		iv
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions</b>	<b>1</b>
<b>4</b>	<b>Wear mechanisms</b>	<b>2</b>
<b>5</b>	<b>Types of abrasion test</b>	<b>3</b>
<b>6</b>	<b>Abradants</b>	<b>8</b>
<b>7</b>	<b>Test conditions</b>	<b>9</b>
	7.1 Temperature	9
	7.2 Degree and rate of slip	9
	7.3 Contact pressure	9
	7.4 Continuous/intermittent contact	9
	7.5 Lubricants and contamination	9
<b>8</b>	<b>Abrasion test apparatus</b>	<b>10</b>
<b>9</b>	<b>Reference materials</b>	<b>12</b>
<b>10</b>	<b>Test procedure</b>	<b>12</b>
<b>11</b>	<b>Expression of results</b>	<b>13</b>
<b>Bibliography</b>		<b>15</b>