# DIN EN 13631-14:2026-04 (E)

## Explosives for civil uses - Explosives for blasting, boosters and explosive substances - Part 14: Verification of the velocity of detonation of explosives for blasting

## Contents

Page


European foreword ..... 3

1 Scope ..... 5

2 Normative references ..... 5

3 Terms and definitions ..... 5

4 Principle ..... 5

5 Apparatus ..... 5

6 Preparation of test sample ..... 6
6.1 General ..... 6
6.2 Test without confinement ..... 6
6.3 Test under confinement ..... 7

7 Procedure ..... 8
7.1 Attachment of the means to measure the velocity of detonation ..... 8
7.1.1 Start-stop method ..... 8
7.1.2 Continuous method ..... 8
7.2 Attachment of the means of initiation ..... 9
7.2.1 Initiation by means of a detonator ..... 9
7.2.2 Initiation by means of a booster ..... 10
7.2.3 Initiation by means of a detonating cord ..... 11
7.3 Measurement procedure ..... 13

8 Expression of results ..... 13

9 Test report ..... 13

Annex ZA (informative) Relationship between this European Standard and the essential requirements of Directive 2014/28/EU relating to the making available on the market and supervision of explosives for civil uses aimed to be covered ..... 15

Bibliography ..... 16