DIN EN ISO 13297:2013-01 (E)

Small craft - Electrical systems - Alternating current installations (ISO 13297:2012)

Contents

Page

Foreword 3

1 Scope 4

2 Normative references 4

3 Terms and definitions 4

4 General requirements 7

5 Marking 9

6 Ignition sources 10

7 Overcurrent protection 10
7.1 General 10
7.2 Supply circuits 10
7.3 Branch circuits 11

8 Ground-fault protection/earth-leakage protection 11

9 Appliances and equipment 11

10 System wiring 11

11 Conductor and cable installation 12

12 Panel boards (switchboards) 14

13 Socket outlets 14

14 Power source options 15

15 Inverters and inverter/chargers 15

Annex A (normative) Conductor requirements 18

Annex B (normative) Instructions to be included with owner s manual 20

Annex C (informative) Recommended system tests 21

Annex D (informative) Typical a.c. system diagrams 22

Annex E (informative) Typical battery charger/inverter diagrams 26

Bibliography 28

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 94/25/EC, as amended by Directive 2003/44/EC 29