DIN EN ISO 13297:2015-04 (E)

Small craft - Electrical systems - Alternating current installations (ISO 13297:2014)

Contents

Page

Foreword 3

1 Scope 4

2 Normative references 4

3 Termsanddefinitions 4

4 General requirements 7

5 Marking 9

6 Ignition sources 10

7 Overcurrent protection 10
7.1 General 10
7.2 Supply circuits 11
7.3 Branch circuits 11

8 Ground-fault protection/earth-leakage protection 11

9 Appliances and equipment 12

10 System wiring 12

11 Conductor and cable installation 13

12 Panel boards (switchboards) 14

13 Socket outlets 15

14 Power source options 15

15 Inverters and inverter/chargers 18

Annex A (normative) Conductor requirements 18

Annex B (normative) Instructions to be included with owner's manual 20

Annex C (informative) Recommended system tests 21

Annex D (informative) Typical a.c. system diagrams 22

Bibliography 31

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 94/25/EC as amended by Directive 2003/44/EC 30