

DIN EN ISO 13297:2015-04 (E)

Small craft - Electrical systems - Alternating current installations (ISO 13297:2014)

Contents		Page
Foreword		3
1	Scope	4
2	Normative references	4
3	Terms and definitions	4
4	General requirements	7
5	Marking	9
6	Ignition sources	10
7	Overcurrent protection	10
7.1	General	10
7.2	Supply circuits	11
7.3	Branch circuits	11
8	Ground-fault protection/earth-leakage protection	11
9	Appliances and equipment	12
10	System wiring	12
11	Conductor and cable installation	13
12	Panel boards (switchboards)	14
13	Socket outlets	15
14	Power source options	15
15	Inverters and inverterchargers	18
Annex A (normative) Conductor requirements		18
Annex B (normative) Instructions to be included with owner's manual		20
Annex C (informative) Recommended system tests		21
Annex D (informative) Typical a.c. system diagrams		22
Bibliography		31
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 94/25/EC as amended by Directive 2003/44/EC		30