

ISO 16315:2026-02 (E)

Small craft - Electrical systems used for electrical propulsion

Contents

Page

Foreword.....	v
Introduction.....	vi
1 Scope.....	1
2 Normative references.....	1
3 Terms and definitions.....	2
4 General requirements.....	5
4.1 General.....	5
4.2 Components of an electric propulsion system.....	6
4.3 Electric propulsion systems.....	6
4.4 Configuration of electrical systems sharing a common energy source for propulsion and service power.....	8
4.4.1 DC systems.....	8
4.4.2 AC systems.....	8
4.5 Environmental factors.....	9
4.6 Electrical ratings.....	9
4.7 Equipment.....	10
4.7.1 Transformers.....	10
4.7.2 Converters.....	10
4.7.3 Motors.....	10
4.8 Enclosures.....	10
4.9 Identification of equipment and conductors.....	10
4.10 Electromagnetic compatibility (EMC).....	11
4.11 Electrical equipment in the vicinity of batteries.....	11
4.12 Hazardous areas.....	12
4.13 Fire protection.....	12
5 Controls, monitoring, system alerts and trip alarms.....	12
5.1 Electrical/electronic controls for electric propulsion systems.....	12
5.1.1 Controls.....	12
5.1.2 Emergency stop.....	13
5.1.3 Fault trip reset.....	13
5.2 Instruments, alerts and trip alarms.....	13
5.2.1 General.....	13
5.2.2 Operating mode and status.....	14
5.2.3 System alerts.....	14
5.2.4 Fault trip alarms.....	14
6 Protection against electric shock.....	14
6.1 Protection against direct contact.....	14
6.2 Automatic disconnection of supply to the electric propulsion system under fault-to- earth conditions (earthed two-wire DC systems and earthed neutral AC systems).....	15
6.3 Fault-to-earth monitoring for DC fully insulated systems and DC three-wire systems.....	15
6.4 Fault-to-earth tripping in AC non-neutral earthed systems (IT-type system).....	16
7 Protection against overcurrent.....	16
7.1 General.....	16
7.2 Characteristics of protective devices.....	16
7.3 Overcurrent protection devices in the outgoing circuit(s) from a battery.....	17
7.4 Overcurrent protection devices in fully insulated systems.....	17

7.4.1	Single pole overcurrent protection.....	17
7.4.2	Dual pole overcurrent protection.....	17
8	Battery monitoring and installation.....	17
8.1	General arrangements.....	17
8.2	Isolation of batteries or battery banks.....	18
8.3	Operational switching of battery(s) or battery bank(s).....	18
8.4	Permanently energized circuits.....	18
8.5	Ventilation.....	19
9	Electrical installation.....	19
9.1	General.....	19
9.2	Segregation of electrical propulsion system cables.....	19
10	Testing.....	19
10.1	General.....	19
10.2	Earthing and bonding.....	20
10.3	Insulation resistance.....	20
10.3.1	General.....	20
10.3.2	DC electrical propulsion systems.....	20
10.3.3	AC electrical propulsion systems.....	20
10.3.4	Switchboards, panel boards and distribution boards.....	20
10.3.5	Power and lighting final circuits.....	20
10.3.6	Generators and motors.....	21
10.3.7	Transformers.....	21
10.4	Electrical/electronic controls systems for propulsion motor control.....	21
10.5	On load test and inspection of electrical propulsion systems, and associated switch gear and control gear.....	21
10.6	Voltage drop.....	21
	Annex A (normative) Information and instructions for the owner's manual.....	22
	Annex B (normative) Installation documentation.....	23
	Annex C (informative) Electromagnetic compatibility documents.....	24
	Bibliography.....	25