ISO 21919-2:2021 (E)

Physical device control — Interfaces for automated machine tending — Part 2: Safety and control interface

Contents

Foreword

Introduction

1 Scope

2 Normative references

3 Terms and definitions

4 Description of the interfaces

4.1 General
4.2 Characteristics of the interface
4.2.1 General
4.2.2 Conformance class
4.2.2.1 General
4.2.2.2 Conformance class 1: Minimum set of signals
4.2.2.2.1 General
4.2.2.2.2 Simple unloading
4.2.2.2.3 Simple loading
4.2.2.2.4 Simple combined unloading and loading
4.2.2.3 Conformance class 2: Extended set of signals
4.2.2.3.1 General
4.2.2.3.2 Unloading with non-coherent transfer, with/without clamping function
4.2.2.3.3 Unloading with coherent transfer
4.2.2.3.4 Loading with non-coherent transfer, with/without clamping function
4.2.2.3.5 Loading with coherent transfer
4.2.2.3.6 Combined unloading and loading with non-coherent transfer, with/without clamping function
4.2.2.3.7 Combined unloading and loading with coherent transfer
4.2.2.3.8 Preparation of a part
4.2.2.3.9 Emptying
4.2.2.3.10 Function of guard doors
4.2.2.3.11 Further status functions
4.2.2.4 Conformance class 3: Extended set of signals with process optimization
4.2.2.4.1 General
4.2.2.4.2 Process optimizations at combined unloading and loading
4.2.2.4.2.1 General
4.2.2.4.2.2 With coherent transfer
4.2.2.4.2.3 With non-coherent transfer, with/without clamping function
4.2.2.4.3 Process optimizations, if pre-positioning by machine
4.2.2.4.4 Process optimizations, if clamping and releasing is executed in more than one step
4.2.3 Conformance options
4.2.3.1 General
4.2.3.2 Conformance option: Loading access controlled by machine
4.2.3.3 Conformance option: Loading access controlled by automated machine tending system
4.2.3.4 Conformance option: Enabling device
4.2.3.5 Conformance option: Monitoring of communication
4.2.3.6 Conformance option: Tool life management
4.2.3.7 Conformance option: Central functions
4.2.3.8 Conformance option: Control signals for safety-relevant functions
4.2.3.9 Conformance option: With parts data

4.2.3.9.1 General
4.2.3.9.2 Signals for controlling data handling
4.2.3.9.3 Preparation data and parts data
4.2.3.9.3.1 Signal names and content of preparation data and parts data
4.2.3.9.3.2 Use of preparation data and parts data
4.2.3.10 Conformance option: Setup information
4.2.3.11 Conformance option: Machine panel
4.2.3.12 Conformance option: Part seat control
4.3 Safety interface
4.3.1 General
4.3.2 Principle approach and concept
4.3.3 Matrix for safety-related functional relationships
4.3.4 Distribution of performance levels and PFHD value
4.4 Control interface

5 Extension of the interfaces

5.1 General
5.2 Examples of project-specific extensions
5.2.1 General
5.2.2 Additional signals
5.2.3 More than one interference area
5.2.3.1 Separated safety areas
5.2.3.2 The same safety area

Annex A (normative) List of signals

Annex B (informative) Examples for safety matrices

B.1 General
B.2 Example 1: System configuration with loading setup space without (closable) loading access
B.2.1 Configuration
B.2.2 Safety matrix
B.2.3 Explanation of the scenarios
B.2.3.1 Development of the matrix
B.2.3.2 Scenario 0
B.2.3.3 Scenario 1
B.2.3.4 Scenario 2
B.2.3.5 Scenario 3
B.2.3.6 Scenario 4
B.2.3.7 Scenario 5
B.2.3.8 Scenario 6
B.2.3.9 Scenario 7
B.2.3.10 Scenario 8
B.3 Example 2: Loading setup space with loading access
B.3.1 Configuration
B.3.2 Safety matrix
B.3.3 Explanation of the scenarios
B.3.3.1 Development of the matrix
B.3.3.2 Scenario 0
B.3.3.3 Scenario 1
B.3.3.4 Scenario 2
B.3.3.5 Scenario 3
B.3.3.6 Scenario 4
B.3.3.7 Scenario 5
B.3.3.8 Scenario 6
B.3.3.9 Scenario 7
B.3.3.10 Scenario 8
B.3.3.11 Scenario 9
B.3.3.12 Scenario 10
B.4 Example 3: Loading of workspace with loading access from above for several machines

B.4.1 Configuration
B.4.2 Safety matrix
B.4.3 Explanation of the scenarios

B.4.3.1 Development of the matrix
B.4.3.2 Scenario 0
B.4.3.3 Scenario 1
B.4.3.4 Scenario 2
B.4.3.5 Scenario 3
B.4.3.6 Scenario 4

Annex C (normative) Flow charts

C.1 Conformance class 1
C.1.1 Simple unloading
C.1.2 Simple loading
C.1.3 Simple combined unloading and loading
C.2 Conformance class 2
C.2.1 Unloading with non-coherent transfer, with/without clamping function
C.2.2 Unloading with coherent transfer
C.2.3 Loading with non-coherent transfer, with/without clamping function
C.2.4 Loading with coherent transfer
C.2.5 Combined unloading and loading with non-coherent transfer, with/without clamping function
C.2.6 Combined unloading and loading with coherent transfer
C.2.7 Emptying
C.2.8 Functions of guard doors
C.3 Conformance class 3
C.3.1 Process optimizations at the combined unloading and loading with non-coherent transfer, with/without clamping function
C.3.2 Process optimizations at the combined unloading and loading with coherent transfer
C.4 Conformance options
C.4.1 Monitoring of communication
C.4.2 Conformance option: With parts data
C.4.2.1 Loading with preparation data from the machine to the automated machine tending system
C.4.2.2 Unloading with preparation data from the machine to the automated machine tending system
C.4.2.3 Loading with preparation data from the automated machine tending system to the machine
C.4.2.4 Unloading with preparation data from the automated machine tending system to the machine
C.4.2.5 Unloading with parts data
C.4.2.6 Loading with parts data
C.4.2.7 Loading with part reference number
C.4.3 Conformance option: Part seat control

Page count: 44