

# ISO/IEC 17760-102:2016-03 (E)

## Information technology - AT Attachment - Part 102: ATA/ATAPI Command set - 2 (ACS-2)

---

Contents	Page
FOREWORD.....	15
INTRODUCTION .....	17
1 Scope .....	19
2 Normative references .....	19
3 Terms, definitions, abbreviations, and conventions .....	20
3.1 Terms and definitions .....	20
3.2 Symbols and abbreviations .....	28
3.2.1 Abbreviations .....	28
3.2.2 Units .....	30
3.2.3 Symbols .....	30
3.2.4 Mathematical operators .....	30
3.3 Conventions .....	30
3.3.1 Overview .....	30
3.3.2 Precedence .....	31
3.3.3 Lists .....	31
3.3.4 Keywords .....	32
3.3.5 Numbering .....	33
3.3.6 Bit conventions .....	33
3.3.7 Number range convention .....	34
3.3.8 State diagram conventions .....	34
3.3.9 Byte, word, DWord, and QWord Relationships .....	35
3.3.10 ATA string convention .....	36
3.3.11 Offset Convention .....	37
4 Feature set definitions .....	38
4.1 Overview .....	38
4.2 General feature set .....	38
4.3 The PACKET feature set .....	39
4.3.1 Overview .....	39
4.3.2 Identification of PACKET feature set devices .....	39
4.3.3 Signature for ATAPI devices .....	39
4.3.4 The PACKET command .....	40
4.4 48-bit Address feature set .....	40
4.5 Advanced Power Management (APM) feature set .....	40
4.6 CompactFlash Association (CFA) feature set .....	41
4.7 Device Configuration Overlay (DCO) feature set .....	41
4.8 Extended Power Conditions (EPC) feature set .....	44
4.8.1 Overview .....	44
4.8.2 Power conditions .....	44
4.8.3 Power condition timers .....	45
4.8.4 Interaction with resets, commands and other features if the EPC feature set is enabled .....	45
4.9 Free-fall Control feature set .....	46
4.10 General Purpose Logging (GPL) feature set .....	47
4.11 Host Protected Area (HPA) feature set .....	47
4.11.1 HPA overview .....	47
4.11.2 HPA security extensions .....	47
4.11.3 28-bit and 48-bit HPA commands interactions .....	48

4.11.4 IDENTIFY DEVICE data .....	49
4.11.5 Determination of SET MAX security extension status .....	50
4.11.6 HPA State Transition Diagrams .....	50
4.12 Long Logical Sector (LLS) feature set .....	66
4.13 Long Physical Sector (LPS) feature set .....	67
4.14 Native Command Queuing (NCQ) feature set .....	69
4.14.1 Overview .....	69
4.14.2 Priority .....	69
4.14.3 Unload .....	69
4.14.4 Command Phases .....	70
4.15 NV Cache feature set .....	70
4.16 NV Cache Power Management feature set .....	72
4.17 Power Management feature set .....	72
4.17.1 Overview .....	72
4.17.2 Power management commands .....	73
4.17.3 Standby timer .....	73
4.17.4 Power modes .....	74
4.18 Power-Up In Standby (PUIS) feature set .....	77
4.19 Sanitize Device feature set .....	77
4.20 Security feature set .....	81
4.20.1 Overview .....	81
4.20.2 Passwords .....	81
4.20.3 Master Password Capability .....	81
4.20.4 Frozen Mode .....	82
4.20.5 Commands .....	82
4.20.6 IDENTIFY DEVICE data .....	82
4.20.7 Security initial setting .....	82
4.20.8 Password Rules .....	82
4.20.9 Password attempt counter .....	82
4.20.10 Security states .....	84
4.20.11 Master Password Identifier feature .....	93
4.21 Self-Monitoring, Analysis, and Reporting Technology (SMART) feature set .....	94
4.21.1 Overview .....	94
4.21.2 Device SMART data structure .....	94
4.21.3 Background data collection .....	94
4.21.4 Off-line/Captive mode data collection .....	94
4.21.5 Threshold exceeded condition .....	94
4.21.6 SMART feature set commands .....	94
4.21.7 SMART operation with power management modes .....	94
4.21.8 SMART device error log reporting .....	95
4.22 Sense Data Reporting feature set .....	95
4.23 Software Settings Preservation (SSP) feature set .....	95
4.24 Streaming feature set .....	96
4.24.1 Streaming feature set overview .....	96
4.24.2 Streaming commands .....	96
4.25 Trusted Computing feature set .....	97
4.26 Write-Read-Verify feature set .....	98
5 ATA protocols .....	100
6 Normal and Error Output field descriptions .....	101
6.1 Overview .....	101
6.2 Status field .....	101
6.2.1 Overview .....	101
6.2.2 Alignment Error .....	101
6.2.3 Busy bit .....	102
6.2.4 Check Condition bit .....	102
6.2.5 Data Request bit .....	102
6.2.6 Deferred Write Error bit .....	102
6.2.7 Device Fault bit .....	102
6.2.8 Device Ready bit .....	102
6.2.9 Error bit .....	102
6.2.10 Sense Data Available .....	102
6.2.11 Stream Error bit .....	102

6.2.12 Transport Dependent (TD) .....	103
6.3 Error field .....	103
6.3.1 Overview .....	103
6.3.2 Abort bit .....	103
6.3.3 Attempted Partial Range Removal bit .....	103
6.3.4 Command Completion Time Out bit .....	103
6.3.5 End of Media bit .....	103
6.3.6 ID Not Found bit .....	103
6.3.7 Illegal Length Indicator bit .....	104
6.3.8 Insufficient LBA Range Entries Remaining bit .....	104
6.3.9 Insufficient NV Cache Space bit .....	104
6.3.10 Interface CRC bit .....	104
6.3.11 Media Error bit .....	104
6.3.12 Sense Key field .....	104
6.3.13 Uncorrectable Error bit .....	104
6.4 Interrupt Reason field .....	104
6.4.1 Overview .....	104
6.4.2 Command/Data bit .....	104
6.4.3 Input/Output (I/O) bit .....	104
6.5 Count field .....	105
6.5.1 Overview .....	105
6.5.2 NCQ Tag field .....	105
6.6 SActive field .....	105
6.7 SATA Status .....	105
7 Command descriptions .....	106
7.1 Command description introduction .....	106
7.2 CFA ERASE SECTORS - C0h, Non-Data .....	110
7.3 CFA REQUEST EXTENDED ERROR CODE - 03h, Non-Data .....	111
7.4 CFA TRANSLATE SECTOR - 87h, PIO Data-In .....	113
7.5 CFA WRITE MULTIPLE WITHOUT ERASE - CDh, PIO Data-Out .....	114
7.6 CFA WRITE SECTORS WITHOUT ERASE - 38h, PIO Data-Out .....	115
7.7 CHECK POWER MODE - E5h, Non-Data .....	116
7.8 CONFIGURE STREAM - 51h, Non-Data .....	117
7.9 DATA SET MANAGEMENT - 06h, DMA .....	119
7.10 Device Configuration Overlay (DCO) .....	121
7.10.1 DCO Overview .....	121
7.10.2 DEVICE CONFIGURATION FREEZE LOCK - B1h/C1h, Non-Data .....	122
7.10.3 DEVICE CONFIGURATION IDENTIFY - B1h/C2h, PIO Data-In .....	123
7.10.4 DEVICE CONFIGURATION IDENTIFY DMA - B1h/C4h, DMA .....	128
7.10.5 DEVICE CONFIGURATION RESTORE - B1h/C0h, Non-Data .....	129
7.10.6 DEVICE CONFIGURATION SET - B1h/C3h, PIO Data-Out .....	130
7.10.7 DEVICE CONFIGURATION SET DMA - B1h/C5h, DMA .....	141
7.11 DEVICE RESET - 08h, Device Reset .....	142
7.12 DOWNLOAD MICROCODE - 92h, PIO Data-Out/Non-Data .....	143
7.13 DOWNLOAD MICROCODE DMA - 93h, DMA .....	146
7.14 EXECUTE DEVICE DIAGNOSTIC - 90h, Execute Device Diagnostic .....	147
7.15 FLUSH CACHE - E7h, Non-Data .....	149
7.16 FLUSH CACHE EXT - EAh, Non-Data .....	150
7.17 IDENTIFY DEVICE - ECh, PIO Data-In .....	151
7.18 IDENTIFY PACKET DEVICE - A1h, PIO Data-In .....	193
7.19 IDLE - E3h, Non-Data .....	211
7.20 IDLE IMMEDIATE - E1h, Non-Data .....	212
7.21 Non-Volatile Cache .....	214
7.21.1 NV Cache Overview .....	214
7.21.2 NV Cache Power Management Overview .....	214
7.21.3 ADD LBA(S) TO NV CACHE PINNED SET - B6h/10h, DMA .....	216
7.21.4 FLUSH NV CACHE - B6h/14h, Non-Data .....	218
7.21.5 NV CACHE DISABLE - B6h/16h, Non-Data .....	219

7.21.6 NV CACHE ENABLE - B6h/15h, Non-Data .....	220
7.21.7 QUERY NV CACHE MISSES - B6h/13h, DMA .....	221
7.21.8 QUERY NV CACHE PINNED SET - B6h/12h, DMA .....	223
7.21.9 REMOVE LBA(S) FROM NV CACHE PINNED SET - B6h/11h, DMA/Non-Data ..	224
7.21.10 RETURN FROM NV CACHE POWER MODE - B6h/01h, Non-Data.....	226
7.21.11 SET NV CACHE POWER MODE - B6h/00h, Non-Data .....	227
7.22 NOP - 00h, Non-Data .....	228
7.23 PACKET - A0h, Packet .....	229
7.24 READ BUFFER - E4h, PIO Data-In .....	232
7.25 READ BUFFER DMA - E9h, DMA .....	233
7.26 READ DMA - C8h, DMA .....	234
7.27 READ DMA EXT - 25h, DMA .....	235
7.28 READ FPDMA QUEUED - 60h, DMA Queued .....	236
7.29 READ LOG EXT - 2Fh, PIO Data-In .....	238
7.30 READ LOG DMA EXT - 47h, DMA .....	240
7.31 READ MULTIPLE - C4h, PIO Data-In .....	241
7.32 READ MULTIPLE EXT - 29h, PIO Data-In .....	243
7.33 READ NATIVE MAX ADDRESS - F8h, Non-Data .....	244
7.34 READ NATIVE MAX ADDRESS EXT - 27h, Non-Data .....	245
7.35 READ SECTOR(S) - 20h, PIO Data-In .....	246
7.36 READ SECTOR(S) EXT - 24h, PIO Data-In .....	247
7.37 READ STREAM DMA EXT - 2Ah, DMA .....	248
7.38 READ STREAM EXT - 2Bh, PIO Data-In .....	251
7.39 READ VERIFY SECTOR(S) - 40h, Non-Data .....	252
7.40 READ VERIFY SECTOR(S) EXT - 42h, Non-Data .....	253
7.41 REQUEST SENSE DATA EXT - 0Bh, Non-Data .....	254
7.42 Sanitize Device .....	255
7.42.1 Sanitize Device Overview .....	255
7.42.2 BLOCK ERASE EXT – B4h/0012h, Non-Data.....	256
7.42.3 CRYPTO SCRAMBLE EXT – B4h/0011h, Non-Data .....	258
7.42.4 OVERWRITE EXT – B4h/0014h, Non-Data .....	260
7.42.5 SANITIZE FREEZE LOCK EXT – B4h/0020h, Non-Data .....	262
7.42.6 SANITIZE STATUS EXT – B4h/0000h, Non-Data .....	263
7.43 SECURITY DISABLE PASSWORD - F6h, PIO Data-Out .....	265
7.44 SECURITY ERASE PREPARE - F3h, Non-Data .....	267
7.45 SECURITY ERASE UNIT - F4h, PIO Data-Out .....	268
7.46 SECURITY FREEZE LOCK - F5h, Non-Data .....	270
7.47 SECURITY SET PASSWORD - F1h, PIO Data-Out .....	271
7.48 SECURITY UNLOCK - F2h, PIO Data-Out .....	273
7.49 SET FEATURES - EFh, Non-Data .....	275
7.49.1 Feature Set .....	275
7.49.2 Description .....	275
7.49.3 Enable/disable 8-bit PIO data transfer .....	277
7.49.4 Enable/disable volatile write cache .....	277
7.49.5 Set transfer mode .....	278
7.49.6 Enable/disable the APM feature set .....	279
7.49.7 Enable/disable the PUIS feature set .....	279
7.49.8 PUIS feature set device spin-up .....	279
7.49.9 Enable/disable CFA power mode 1 .....	279
7.49.10 Enable/Disable Write-Read-Verify feature set .....	280
7.49.11 Set Maximum Host Interface Sector Times .....	281
7.49.12 Enable/disable read look-ahead .....	281
7.49.13 Enable/disable reverting to defaults .....	281
7.49.14 Enable/Disable the Free-fall Control feature set .....	281
7.49.15 Enable/Disable SATA feature .....	282
7.49.16 Enable/Disable the Sense Data Reporting feature set .....	283
7.49.17 Long Physical Sector Alignment Error Reporting Control .....	283
7.49.18 Extended power conditions .....	283
7.50 SET MAX .....	293

7.50.2 SET MAX ADDRESS - F9h, Non-Data .....	294
7.50.3 SET MAX FREEZE LOCK - F9h/04h, Non-Data .....	297
7.50.4 SET Max Feature Control Formatch, Non-Data .....	297
7.50.5 SET Max Table Password - F9h/01h, PIO Data-Out .....	298
7.50.6 SET MAX SET PASSWORD DMA - F9h/05h, DMA .....	300
9 Normal Set Max Output Lock - F9h/03h, PIO Data-Out .....	304
9.1.0.9.8 SET MAX UNLOCK DMA - F9h/06h, DMA .....	304
7.51.2 SET MAX ADDRESS EXT - 37h, Non-Data .....	304
7.52 SET MULTIPLE MODE - C6h, Non-Data .....	305
7.53 SLEEP - E6h, Non-Data .....	308
7.54 SMART .....	309
7.54.1 Overview .....	309
7.54.2 SMART DISABLE OPERATIONS - B0h/D9h, Non-Data .....	310
7.54.3 SMART ENABLE/DISABLE ATTRIBUTE AUTOSAVE - B0h/D2h, Non-Data .....	311
7.54.4 SMART ENABLE OPERATIONS - B0h/D8h, Non-Data .....	313
7.54.5 SMART EXECUTE OFF-LINE IMMEDIATE - B0h/D4h, Non-Data .....	314
7.54.6 SMART READ DATA - B0h/D0h, PIO Data-In .....	318
7.54.7 SMART READ LOG - B0h/D5h, PIO Data-In .....	323
7.54.8 SMART RETURN STATUS - B0h/DAh, Non-Data .....	324
7.54.9 SMART WRITE LOG - B0h/D6h, PIO Data-Out .....	325
7.55 STANDBY - E2h, Non-Data .....	326
7.56 STANDBY IMMEDIATE - E0h, Non-Data .....	327
7.57 TRUSTED NON-DATA - 5Bh, Non-Data .....	328
7.58 TRUSTED RECEIVE - 5Ch, PIO Data-In .....	329
7.59 TRUSTED RECEIVE DMA - 5Dh, DMA .....	333
7.60 TRUSTED SEND - 5Eh, PIO Data-Out .....	334
7.61 TRUSTED SEND DMA - 5Fh, DMA .....	336
7.62 WRITE BUFFER - E8h, PIO Data-Out .....	337
7.63 WRITE BUFFER DMA - EBh, DMA .....	338
7.64 WRITE DMA - CAh, DMA .....	339
7.65 WRITE DMA EXT - 35h, DMA .....	340
7.66 WRITE DMA FUA EXT - 3Dh, DMA .....	341
7.67 WRITE FPDMA QUEUED - 61h, DMA Queued .....	342
7.68 WRITE LOG EXT - 3Fh, PIO Data-Out .....	344
7.69 WRITE LOG DMA EXT - 57h, DMA .....	346
7.70 WRITE MULTIPLE - C5h, PIO Data-Out .....	347
7.71 WRITE MULTIPLE EXT - 39h, PIO Data-Out .....	348
7.72 WRITE MULTIPLE FUA EXT - CEh, PIO Data-Out .....	350
7.73 WRITE SECTOR(S) - 30h, PIO Data-Out .....	352
7.74 WRITE SECTOR(S) EXT - 34h, PIO Data-Out .....	353
7.75 WRITE STREAM DMA EXT - 3Ah, DMA .....	354
7.76 WRITE STREAM EXT - 3Bh, PIO Data-Out .....	357
7.77 WRITE UNCORRECTABLE EXT - 45h, Non-Data .....	358
8 SCT Command Transport .....	360
8.1 General .....	360
8.1.1 Overview .....	360
8.1.2 SCT command nesting and interspersing with standard commands .....	360
8.1.3 Resets .....	360
8.2 Processing SCT commands .....	361
8.2.1 Processing SCT commands overview .....	361
8.2.2 SCT capability identification .....	361
8.2.3 SCT command transfer .....	361
8.2.4 SCT data transfer .....	366
8.2.5 SCT status .....	367
8.3 SCT Command Set .....	371
8.3.1 Overview .....	371
8.3.2 SCT Write Same command .....	372
8.3.3 SCT Error Recovery Control command .....	375

8.3.4 SCT Feature Control command .....	377
8.3.5 SCT Data Table command .....	380
9 Normal and Error Outputs .....	384
9.1 Overview .....	384
9.2 Normal Outputs .....	384
9.3 Error Outputs .....	405

## Tables

Table 1 - Numbering conventions .....	33
Table 2 - ATA string byte swapping .....	37
Table 3 - ATA firmware revision example .....	37
Table 4 - Feature Set Summary.....	38
Table 5 - Block Size By Command .....	66
Table 6 - Summary of Security States and Security Characteristics .....	84
Table 7 - Security Command Actions .....	85
Table 8 - IDENTIFY settings for Security state SEC1.....	89
Table 9 - IDENTIFY settings for Security state SEC2.....	90
Table 10 - IDENTIFY settings for Security state SEC4.....	91
Table 11 - IDENTIFY settings for Security state SEC5.....	92
Table 12 - IDENTIFY settings for Security state SEC6.....	93
Table 13 - Preserved Feature Sets and Settings.....	96
Table 14 - Status field .....	101
Table 15 - Error field .....	103
Table 16 - Interrupt Reason field .....	104
Table 17 - Count field.....	105
Table 18 - Example Command Structure.....	107
Table 19 - Example Normal Output .....	107
Table 20 - Example Error Output .....	108
Table 21 - CFA ERASE SECTORS command inputs.....	110
Table 22 - CFA REQUEST EXTENDED ERROR CODE command inputs.....	111
Table 23 - Extended error codes .....	111
Table 24 - CFA TRANSLATE SECTOR command inputs .....	113
Table 25 - CFA TRANSLATE SECTOR data .....	113
Table 26 - CFA WRITE MULTIPLE WITHOUT ERASE command inputs .....	114
Table 27 - CFA WRITE SECTORS WITHOUT ERASE command inputs .....	115
Table 28 - CHECK POWER MODE command inputs. ....	116
Table 29 - CONFIGURE STREAM command inputs.....	117
Table 30 - DATA SET MANAGEMENT command inputs .....	119
Table 31 - Trim related interactions .....	120
Table 32 - Device Configuration Overlay Feature field values.....	121
Table 33 - DEVICE CONFIGURATION FREEZE LOCK command inputs.....	122
Table 34 - DEVICE CONFIGURATION IDENTIFY command inputs .....	123
Table 35 - Device Configuration Identify data structure.....	124
Table 36 - DEVICE CONFIGURATION IDENTIFY DMA command inputs. ....	128
Table 37 - DEVICE CONFIGURATION RESTORE command inputs. ....	129
Table 38 - DEVICE CONFIGURATION SET command inputs.....	130
Table 39 - Device Configuration Overlay (DCO) data structure.....	132
Table 40 - DEVICE CONFIGURATION SET DMA command inputs.....	141
Table 41 - DEVICE RESET command inputs.....	142
Table 42 - DOWNLOAD MICROCODE command inputs.....	144
Table 43 - Count field output for DOWNLOAD MICROCODE requesting the offset transfer method .....	144
Table 44 - DOWNLOAD MICROCODE DMA command inputs.....	146
Table 45 - EXECUTE DEVICE DIAGNOSTIC command inputs.....	147
Table 46 - Diagnostic codes .....	148
Table 47 - FLUSH CACHE command inputs .....	149
Table 48 - FLUSH CACHE EXT command inputs .....	150
Table 49 - IDENTIFY DEVICE command inputs.....	151
Table 50 - IDENTIFY DEVICE data .....	152
Table 51 - Specific configuration.....	171
Table 52 - Minor version number .....	178
Table 53 - Normal Erase Mode Time.....	184
Table 54 - Enhanced Erase Mode Time .....	184
Table 55 - IDENTIFY DEVICE data World Wide Name field (word-based view).....	187
Table 56 - IDENTIFY DEVICE data World Wide Name field (byte-based view).....	188

Table 57 - Device Nominal Form Factor .....	189
Table 58 - Nominal Media Rotation Rate .....	190
Table 59 - Transport minor version number .....	191
Table 60 - IDENTIFY PACKET DEVICE command inputs .....	193
Table 61 - IDENTIFY PACKET DEVICE data .....	194
Table 62 - IDLE command inputs .....	211
Table 63 - Standby timer periods .....	211
Table 64 - IDLE IMMEDIATE command inputs .....	212
Table 65 - IDLE IMMEDIATE with Unload command inputs .....	213
Table 66 - NV Cache Commands .....	214
Table 67 - NV Cache Power Management Commands .....	215
Table 68 - ADD LBA(S) TO NV CACHE PINNED SET command inputs .....	216
Table 69 - LBA Range Entries .....	217
Table 70 - ADD LBA(S) TO NV CACHE PINNED SET command inputs .....	218
Table 71 - NV CACHE DISABLE command inputs .....	219
Table 72 - NV CACHE ENABLE command inputs .....	220
Table 73 - QUERY NV CACHE MISSES command inputs .....	221
Table 74 - Cache Miss Data .....	222
Table 75 - QUERY NV CACHE PINNED SET command inputs .....	223
Table 76 - Pin Set Data .....	223
Table 77 - QUERY NV CACHE PINNED SET command inputs .....	224
Table 78 - Remove Pin Data .....	225
Table 79 - QUERY NV CACHE PINNED SET command inputs .....	226
Table 80 - QUERY NV CACHE PINNED SET command inputs .....	227
Table 81 - NOP command inputs .....	228
Table 82 - NOP Subcommand Code .....	228
Table 83 - PACKET command inputs .....	229
Table 84 - READ BUFFER command inputs .....	232
Table 85 - READ BUFFER DMA command inputs .....	233
Table 86 - READ DMA command inputs .....	234
Table 87 - READ DMA EXT command inputs .....	235
Table 88 - READ FPDMA QUEUED command inputs .....	236
Table 89 - READ LOG EXT command inputs .....	238
Table 90 - READ LOG DMA EXT command inputs .....	240
Table 91 - READ MULTIPLE command inputs .....	241
Table 92 - READ MULTIPLE EXT command inputs .....	243
Table 93 - READ NATIVE MAX ADDRESS command inputs .....	244
Table 94 - READ NATIVE MAX ADDRESS EXT command inputs .....	245
Table 95 - READ SECTOR(S) command inputs .....	246
Table 96 - READ SECTOR(S) EXT command inputs .....	247
Table 97 - READ STREAM DMA EXT command inputs .....	248
Table 98 - READ STREAM EXT command inputs .....	251
Table 99 - READ VERIFY SECTOR(S) command inputs .....	252
Table 100 - READ VERIFY SECTOR(S) EXT command inputs .....	253
Table 101 - REQUEST SENSE DATA EXT command inputs .....	254
Table 102 - Sanitize Device Feature Field Values .....	255
Table 103 - BLOCK ERASE EXT command inputs .....	256
Table 104 - CRYPTO SCRAMBLE EXT command inputs .....	258
Table 105 - OVERWRITE EXT command inputs .....	260
Table 106 - SANITIZE FREEZE LOCK EXT command inputs .....	262
Table 107 - SANITIZE STATUS EXT command inputs .....	263
Table 108 - SECURITY DISABLE PASSWORD command inputs .....	266
Table 109 - SECURITY DISABLE PASSWORD data content .....	266
Table 110 - SECURITY ERASE PREPARE command inputs .....	267
Table 111 - SECURITY ERASE UNIT command inputs .....	269
Table 112 - SECURITY ERASE UNIT data content .....	269
Table 113 - SECURITY FREEZE LOCK command inputs .....	270
Table 114 - SECURITY SET PASSWORD command inputs .....	272
Table 115 - SECURITY SET PASSWORD data content .....	272

Table 116 - SECURITY UNLOCK command inputs .....	273
Table 117 - SECURITY UNLOCK data content .....	274
Table 118 - SET FEATURES Feature field definitions .....	275
Table 119 - Transfer modes .....	278
Table 120 - APM levels .....	279
Table 121 - Write-Read-Verify modes .....	280
Table 122 - Maximum Host Interface Sector Times .....	281
Table 123 - SATA features .....	282
Table 124 - Extended Power Conditions Subcommands .....	284
Table 125 - Power Condition IDs .....	284
Table 126 - Restore Power Condition Settings inputs .....	285
Table 127 - Go To Power Condition inputs .....	286
Table 128 - Set Power Condition Timer inputs .....	287
Table 129 - Set Power Condition State inputs .....	289
Table 130 - Enable the EPC feature set inputs .....	290
Table 131 - Disable the EPC feature set inputs .....	291
Table 132 - SET FEATURES command inputs .....	292
Table 133 - SET MAX Feature field values .....	293
Table 134 - SET MAX ADDRESS command inputs .....	295
Table 135 - SET MAX FREEZE LOCK command inputs .....	297
Table 136 - SET MAX FREEZE LOCK command inputs .....	298
Table 137 - SET MAX SET PASSWORD command inputs .....	299
Table 138 - SET MAX SET PASSWORD data content .....	299
Table 139 - SET MAX SET PASSWORD DMA command inputs .....	300
Table 140 - SET MAX UNLOCK command inputs .....	301
Table 141 - SET MAX UNLOCK DMA command inputs .....	303
Table 142 - SET MAX ADDRESS EXT command inputs .....	304
Table 143 - SET MULTIPLE MODE command inputs .....	307
Table 144 - SLEEP command inputs .....	308
Table 145 - SMART Feature field values .....	309
Table 146 - SMART DISABLE OPERATIONS command inputs .....	310
Table 147 - SMART ENABLE/DISABLE ATTRIBUTE AUTOSAVE command inputs .....	311
Table 148 - SMART ENABLE OPERATIONS command inputs .....	313
Table 149 - SMART EXECUTE OFF-LINE IMMEDIATE Subcommands .....	314
Table 150 - SMART EXECUTE OFF-LINE IMMEDIATE command inputs .....	317
Table 151 - SMART READ DATA command inputs .....	318
Table 152 - Device SMART data structure .....	319
Table 153 - Off-line data collection status byte values .....	320
Table 154 - Self-test execution status values .....	320
Table 155 - Offline Data Collection Capabilities .....	321
Table 156 - SMART READ LOG command inputs .....	323
Table 157 - SMART RETURN STATUS command inputs .....	324
Table 158 - SMART WRITE LOG command inputs .....	325
Table 159 - STANDBY command inputs .....	326
Table 160 - STANDBY IMMEDIATE command inputs .....	327
Table 161 - TRUSTED NON-DATA command inputs .....	328
Table 162 - TRUSTED RECEIVE command inputs .....	330
Table 163 - TRUSTED RECEIVE Security Protocol field description .....	330
Table 164 - Security Protocol 00h – SP Specific field descriptions for Protocol 00h .....	331
Table 165 - TRUSTED RECEIVE parameter data for SP Specific=0000h .....	331
Table 166 - TRUSTED RECEIVE parameter data for SP Specific=0001h .....	332
Table 167 - TRUSTED RECEIVE DMA command inputs .....	333
Table 168 - TRUSTED SEND command inputs .....	334
Table 169 - TRUSTED SEND – Security Protocol field description .....	335
Table 170 - TRUSTED SEND DMA command inputs .....	336
Table 171 - WRITE BUFFER command inputs .....	337
Table 172 - WRITE BUFFER DMA command inputs .....	338
Table 173 - WRITE DMA command inputs .....	339
Table 174 - WRITE DMA EXT command inputs .....	340

Table 175 - WRITE DMA FUA EXT command inputs.....	341
Table 176 - WRITE FPDMA QUEUED command inputs.....	342
Table 177 - WRITE LOG EXT command inputs.....	344
Table 178 - WRITE LOG DMA EXT command inputs.....	346
Table 179 - WRITE MULTIPLE command inputs.....	347
Table 180 - WRITE MULTIPLE EXT command inputs.....	348
Table 181 - WRITE MULTIPLE FUA EXT command inputs.....	350
Table 182 - WRITE SECTOR(S) command inputs.....	352
Table 183 - WRITE SECTOR(S) EXT command inputs.....	353
Table 184 - WRITE STREAM DMA EXT command inputs.....	354
Table 185 - WRITE STREAM EXT command inputs.....	357
Table 186 - WRITE UNCORRECTABLE EXT command inputs.....	359
Table 187 - Fields to issue an SCT command using SMART WRITE LOG.....	361
Table 188 - Fields to issue an SCT command using WRITE LOG (DMA) EXT.....	362
Table 189 - Successful SCT command response.....	363
Table 190 - SCT command error response.....	364
Table 191 - Extended Status codes.....	365
Table 192 - SCT data transfer using SMART.....	366
Table 193 - SCT data transfer using the GPL feature set.....	367
Table 194 - SCT status request using SMART READ LOG.....	368
Table 195 - SCT status request using the GPL feature set.....	369
Table 196 - Format of SCT status response.....	369
Table 197 - SCT command format.....	371
Table 198 - SCT Action Codes.....	371
Table 199 - SCT Write Same command.....	373
Table 200 - SCT Write Same command status response.....	373
Table 201 - SCT Error Recovery Control command.....	375
Table 202 - SCT Error Recovery Control command status response.....	376
Table 203 - SCT Feature Control command.....	377
Table 204 - Feature Code list.....	378
Table 205 - SCT Feature Control command status response.....	379
Table 206 - SCT Data Table command.....	380
Table 207 - SCT Data Tables (by Table Identifier).....	380
Table 208 - Absolute HDA Temperature.....	381
Table 209 - SCT Data Table command status response.....	383
Table 210 - Error Bit Defined For Normal Output.....	384
Table 211 - Extended Error Code for Normal Output.....	385
Table 212 - Generic Normal Output (No LBA Return Value) for Normal Output.....	386
Table 213 - Download Microcode Normal Output.....	387
Table 214 - CFA Normal Output.....	388
Table 215 - Check Power Mode Normal Output.....	389
Table 216 - Stream Normal Output.....	391
Table 217 - Device Signatures for Normal Output.....	392
Table 218 - IDLE Unload Normal Output.....	393
Table 219 - ATAPI Normal Output.....	394
Table 220 - HPA Normal Output.....	395
Table 221 - SMART Off-Line Immediate Normal Output.....	396
Table 222 - SMART Return Status Normal Output.....	397
Table 223 - Generic Extended Normal Output.....	398
Table 224 - SETMAX Extended Normal Output.....	399
Table 225 - NV Cache Normal Output.....	400
Table 226 - NV Cache Flush Normal Output.....	401
Table 227 - NCQ Command Acceptance Normal Output.....	402
Table 228 - NCQ Normal Outputs.....	402
Table 229 - REQUEST SENSE DATA EXT Normal Output.....	403
Table 230 - Sanitize Device Normal Output.....	404
Table 231 - Unsupported Command Error.....	406
Table 232 - CFA Erase Error.....	407
Table 233 - CFA Write Error.....	408

Table 234 - CFA Abort Error and Check Power Mode Abort Error .....	409
Table 235 - Generic Abort wo/ICRC Error .....	410
Table 236 - Generic Abort Error .....	411
Table 237 - Trusted Abort Error .....	412
Table 238 - Generic SET MAX Error .....	413
Table 239 - SET MAX Unlock Error .....	414
Table 240 - Configure Stream Error .....	415
Table 241 - Flush Cache Error .....	416
Table 242 - Flush Cache Ext Error .....	417
Table 243 - Read DMA Ext Error .....	418
Table 244 - Read Log Ext Error .....	419
Table 245 - Read PIO Error .....	420
Table 246 - Read Stream Error .....	421
Table 247 - HPA Error .....	422
Table 248 - Write Log Error .....	423
Table 249 - Write Log Ext Error or Data Set Management Error .....	424
Table 250 - SMART Error .....	425
Table 251 - Write Extended Error .....	426
Table 252 - Write Stream Error .....	427
Table 253 - DCO Set Error .....	428
Table 254 - NOP Error .....	429
Table 255 - PACKET command Error .....	430
Table 256 - SMART Read Log/SMART Read Data Error .....	431
Table 257 - Read PIO Extended Error .....	432
Table 258 - Read Native Max Extended Error .....	433
Table 259 - SETMAX Extended Error .....	434
Table 260 - Write Error .....	435
Table 261 - Write DMA Error .....	436
Table 262 - NV Cache Add Abort Error .....	437
Table 263 - NV Cache Remove Abort Error .....	438
Table 264 - NV Cache Abort Error .....	439
Table 265 - NV Cache Abort with Data Transfer Error .....	440
Table 266 - NCQ Command Acceptance Error .....	441
Table 267 - NCQ Write Command Aborted Error .....	441
Table 268 - NCQ Read Command Aborted Error .....	442
Table 269 - Sanitize Device Error .....	444
Table A.1 - Example Log Structure .....	445
Table A.2 - Log address definition .....	446
Table A.3 - General Purpose Log Directory .....	447
Table A.4 - SMART Log Directory .....	447
Table A.5 - Comprehensive SMART Error log .....	448
Table A.6 - Defined Device Statistics log pages .....	449
Table A.7 - Example Device Statistic .....	449
Table A.8 - Device Statistic Flags .....	450
Table A.9 - List of supported Device Statistics log pages .....	451
Table A.10 - Free Fall Statistics .....	452
Table A.11 - General Statistics .....	453
Table A.12 - General Error Statistics .....	457
Table A.13 - Rotating Media Statistics .....	458
Table A.14 - Solid State Device Statistics .....	462
Table A.15 - Temperature Statistics .....	463
Table A.16 - Transport Statistics .....	470
Table A.17 - Extended Comprehensive SMART Error log .....	473
Table A.18 - Extended Error log data structure .....	473
Table A.19 - Command data structure .....	474
Table A.20 - Error data structure .....	475
Table A.21 - State field values .....	475
Table A.22 - Idle Power Conditions log page .....	476
Table A.23 - Standby Power Conditions log page .....	477

Table A.24 - Power Conditions log descriptor.....	477
Table A.25 - Extended Self-test log data structure .....	479
Table A.26 - Extended Self-test log descriptor entry .....	479
Table A.27 - LPS Mis-alignment log (log page 0) .....	481
Table A.28 - LPS Mis-alignment log (log pages 1..x).....	482
Table A.29 - NCQ Command Error log .....	483
Table A.30 - Read Stream Error log .....	485
Table A.31 - Stream Error Log Entry .....	485
Table A.32 - SATA Phy Event Counters log Format.....	486
Table A.33 - Selective Self-Test log.....	487
Table A.34 - Selective self-test feature flags .....	488
Table A.35 - Self-test log data structure .....	489
Table A.36 - Self-test log descriptor entry.....	489
Table A.37 - Summary SMART Error log.....	490
Table A.38 - Error log data structure.....	491
Table A.39 - Command data structure .....	492
Table A.40 - Error data structure .....	492
Table A.41 - State field values .....	493
Table A.42 - Write Stream Error log.....	494
Table B.1 - Command Matrix .....	495
Table B.2 - Command codes (sorted by command code) .....	496
Table B.3 - Command codes (sorted by command name) .....	500
Table B.4 - Historical Command Assignments .....	503
Table B.5 - Historical SET FEATURE Code Assignments.....	511
Table D.1 - SCT command using SMART WRITE LOG command .....	529
Table D.2 - SCT command using WRITE LOG EXT command.....	530

## Figures

Figure 1 - ATA document relationships.....	17
Figure 2 - State diagram convention.....	34
Figure 3 - Byte, word, DWord and QWord relationships.....	35
Figure 4 - Device Configuration Overlay state diagram.....	43
Figure 5 - HPA Not Set.....	51
Figure 6 - HPA Set (28).....	52
Figure 7 - HPA Set (48).....	53
Figure 8 - HPA Locked (28).....	54
Figure 9 - HPA Locked (48).....	55
Figure 10 - LLS and LPS Example.....	68
Figure 11 - Alignment 0.....	68
Figure 12 - Alignment 1.....	68
Figure 13 - Alignment 3.....	68
Figure 14 - Power management state diagram.....	74
Figure 15 - Sanitize Device state machine.....	79
Figure 16 - Security state diagram.....	88
Figure 17 - Selective self-test span example.....	316
Figure C.1 - Unaligned Write Example.....	521
Figure D.1 - Example flowchart for SCT commands.....	523
Figure D.2 - Example sequence for foreground write same with a repeating pattern.....	524
Figure D.3 - Example sequence for foreground write same with a repeating sector.....	524
Figure D.4 - Example sequence for writing data using an SCT command with no background activity.....	525
Figure D.5 - Example sequence for reading data using an SCT command with no background activity.....	525
Figure D.6 - Example sequence for a Non-Data SCT command with no background activity.....	526
Figure D.7 - Example sequence for writing data using an SCT command with background activity.....	527
Figure D.8 - Example sequence for a Non-Data SCT command with background activity.....	528
Figure E.1 - System Dependency Chain.....	532
Figure E.2 - Mapping Proposals.....	532
Figure E.3 - Logical Sector to Physical Mapping.....	533
Figure E.4 - Uncorrectable Error Handling.....	535
Figure E.5 - Typical HDD Layout Using A Master Boot Record.....	536