

ISO 14404-1:2024-09 (E)

Calculation method of carbon dioxide emission intensity from iron and steel production - Part 1: Steel plant with blast furnace

Contents		Page
Foreword		iv
Introduction		v
1	Scope	1
2	Normative references	1
3	Terms and definitions	1
3.1	Emissions	1
3.2	Gas fuel	2
3.3	Liquid fuel	2
3.4	Solid fuel	3
3.5	Auxiliary material	4
3.6	Energy carriers	4
3.7	Ferrous containing materials	5
3.8	Alloys	5
3.9	Other imported/exported materials	6
3.10	Others	6
4	Symbols	7
5	Principles	8
5.1	General	8
5.2	Relevance	8
5.3	Completeness	8
5.4	Consistency	8
5.5	Accuracy	8
5.6	Transparency	8
6	Boundary	8
6.1	General	8
6.2	Category 1	9
6.3	Category 2	9
6.4	Category 3	10
6.5	Category 4	10
7	Calculation	10
7.1	General	10
7.2	Calculation procedure	10
7.2.1	Data collection of crude steel production	10
7.2.2	Data collection direct and/or upstream CO ₂ emission sources	11
7.2.3	Data collection of credit CO ₂ emission sources	12
7.2.4	Calculation	14
Annex A (informative)	Calculation of energy consumption and intensity	16
Annex B (informative)	Example of template for using different emission factors or emission sources from Table 4	18

Annex C (informative) Example of CO2 emission and intensity calculations for a steel plant -- Data of a steel plant	20
Annex D (informative) Explanation of emission factors for by-product gases in Table 4	24
Annex E (informative) Decarbonization strategies and its impact on CO2 calculation method	27
Bibliography	28