DIN EN 14825:2012-06 (E)

Air conditioners, liquid chilling pack ages and heat pumps, with electrically driven compressors, for space heating and cooling - Testing and rating at part load conditions and calculation of seasonal performance

Contents

Page

Foreword 4

Introduction 5

1 Scope 6

2 Normative references 6

3 Terms, definitions, symbols, abbreviated terms and units 6
3.1 Terms and definitions 6
3.2 Symbols, abbreviated terms and units 13

4 Part load conditions in cooling mode 15
4.1 General 15
4.2 Air-to-air units 15
4.3 Water-to-air units and brine-to-air units 15
4.4 Air-to-water units 16
4.5 Water-to-water and brine-to-water units 16

5 Part load conditions in heating mode 17
5.1 General 17
5.2 Air-to-air units 18
5.3 Water-to-air and brine-to-air units 19
5.4 Air-to-water units 20
5.4.1 General 20
5.4.2 Low temperature application 21
5.4.3 Medium temperature application 24
5.4.4 High temperature application 26
5.4.5 Very high temperature application 29
5.5 Water-to-water and brine-to-water units 31
5.5.1 General 31
5.5.2 Low temperature application 32
5.5.3 Medium temperature application 35
5.5.4 High temperature application 38
5.5.5 Very high temperature application 41

6 Calculation methods for reference SEER and reference SEERon 43
6.1 General formula for calculation of reference SEER 43
6.2 Calculation of the reference annual cooling demand (Qc) 44
6.3 Calculation of reference SEERon 44
6.4 Calculation procedure for determination of EERPL values at part load conditions B, C, D 45
6.4.1 General 45
6.4.2 For air-to-air & water-to-air units 45
6.4.3 Air-to-water, water-to-water & brine-to-water units 46

7 Calculation methods for reference SCOP, reference SCOPon and reference SCOPnet 47
7.1 General formula for calculation of reference SCOP 47
7.2 Calculation of the reference annual heating demand (Qh) 47
7.3 Calculation of reference SCOPon and reference SCOPnet 48

7.4 Calculation procedure for determination of COPPL values at part load conditions A, B, C, D ... 50
7.4.1 General ... 50
7.4.2 For air-to-air, brine-to-air and water-to-air units ... 50
7.4.3 For air-to-water, water-to-water and brine-to-water units ... 51

8 Test methods for testing capacities, EERPL and COPPL values during active mode at part load conditions ... 52
8.1 General ... 52
8.2 Basic principles ... 52
8.3 Uncertainties of measurement ... 53
8.4 Test procedures for units with fixed capacity ... 54
8.4.1 General ... 54
8.4.2 Air-to-air and water-to-air units - Determination of the degradation coefficient Cd ... 54
8.4.3 Air-to-water units and water-to-water units - Determination of the degradation factor Cc ... 55
8.5 Test procedure for variable capacity units (air-to-air, air-to-water, water-to-air, water/brine-to-water) ... 56
8.5.1 Air-to-air & water-to-air units ... 56
8.5.2 Air-to-water and water/brine-to-water units ... 56

9 Test methods for electric power consumption during thermostat off mode, standby mode and crankcase heater mode ... 56
9.1 Measurement of electric power consumption during thermostat off mode ... 56
9.2 Measurement of the electric power consumption during standby mode ... 57
9.3 Measurement of the electric power consumption during crankcase heater mode ... 57
9.4 Measurement of the electric power consumption during off mode ... 57

10 Test report ... 57

11 Technical data sheet ... 57

Annex A (informative) Calculation example for reference SEERon and reference SEER - Application of an air-to-air unit with variable capacity ... 58

A.1 Calculation of SEERon ... 58
A.2 Calculation of SEER ... 59
A.2.1 Calculation of reference annual cooling demand (Qc) according to Equation (2) ... 59
A.2.2 Calculation of reference SEER according to Equation (1) ... 59

Annex B (informative) Calculation example for reference SCOPon and reference SCOPnet of a fixed capacity air-to-water heat pump used for floor heating ... 60

Annex C (informative) Adaption of water temperature for fixed capacity units ... 64

Annex D (informative) Determination of reference annual cooling/heating demands and determination of hours for active mode, thermostat off, standby, off mode and crankcase heater mode ... 67

D.1 General track ... 67
D.2 Determination of reference annual cooling/heating demands and hours for active mode, thermostat off, standby, off mode ... 67
D.3 Hours used for crankcase heater mode ... 69

Annex E (informative) Compensation method for air-to-water and water/brine-to-water units ... 70

E.1 General ... 70
E.2 Compensation system for reduced capacity test in cooling mode ... 70
E.3 Compensation system for reduced capacity test in heating mode ... 71

Bibliography ... 72