

# ISO 5149-4:2014-04 (E)

## Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, repair and recovery

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>General requirements .....</b>	<b>1</b>
4.1	Operation instructions .....	1
4.2	Instruction of operating personnel .....	2
4.3	Documentation .....	2
<b>5</b>	<b>Maintenance and repair .....</b>	<b>2</b>
5.1	General .....	2
5.2	Maintenance .....	3
5.3	Repair .....	3
5.4	Change of refrigerant type .....	4
<b>6</b>	<b>Requirements for recovery, reuse and disposal .....</b>	<b>5</b>
6.1	General requirements .....	5
6.2	Requirements for recovery and reuse of refrigerant .....	6
6.3	Requirements for refrigerant transfer, transport and storage .....	9
6.4	Requirements for recovery equipment .....	10
6.5	Requirements for disposal .....	11
6.6	Requirements for documentation .....	12
<b>Annex A (normative) Draining the oil from a refrigerating system .....</b>		<b>13</b>
<b>Annex B (informative) Guide specification (parameters) for recycled refrigerant .....</b>		<b>14</b>
<b>Annex C (informative) Handling and storage of refrigerants .....</b>		<b>15</b>
<b>Annex D (informative) In-service inspection .....</b>		<b>20</b>
<b>Annex E (informative) Corrosion inspection .....</b>		<b>22</b>
<b>Bibliography .....</b>		<b>23</b>