

# DIN EN 378-4:2008-06 (E)

## Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, rep air and recovery

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
1	Scope .....	4
2	Normative references .....	4
3	Terms and definitions .....	4
4	General requirements .....	5
4.1	Operational instructions .....	5
4.2	Instruction of operating personnel .....	5
4.3	Documentation .....	5
5	Maintenance and repair .....	6
5.1	General .....	6
5.2	Maintenance .....	6
5.3	Repair .....	7
5.4	Change of refrigerant type .....	8
6	Requirements for recovery, reuse and disposal .....	9
6.1	General requirements .....	9
6.2	Requirements for recovery and reuse of refrigerant .....	10
6.3	Requirements for refrigerant transfer, transport and storage .....	13
6.4	Requirements for recovery equipment .....	14
6.5	Requirements for disposal .....	15
6.6	Requirements for documentation .....	15
Annex A (normative) Draining the oil from a refrigerating system .....		16
Annex B (informative) Guide specification (parameters) for recycled refrigerant .....		17
Annex C (informative) Handling and storage of refrigerants .....		18
Annex D (informative) In-service inspection .....		20
Annex E (informative) Guidelines for repairs of equipment using flammable refrigerants .....		22
Bibliography .....		25