

DIN EN 378-4:2008-06 (E)

Refrigerating systems and heat pumps - Safety and environmental requirements - Part 4: Operation, maintenance, rep air and recovery

Contents		Page
Foreword		3
1	Scope	4
2	Normative references	4
3	Terms and definitions	4
4	General requirements	5
4.1	Operational instructions	5
4.2	Instruction of operating personnel	5
4.3	Documentation	5
5	Maintenance and repair	6
5.1	General	6
5.2	Maintenance	6
5.3	Repair	7
5.4	Change of refrigerant type	8
6	Requirements for recovery, reuse and disposal	9
6.1	General requirements	9
6.2	Requirements for recovery and reuse of refrigerant	10
6.3	Requirements for refrigerant transfer, transport and storage	13
6.4	Requirements for recovery equipment	14
6.5	Requirements for disposal	15
6.6	Requirements for documentation	15
Annex A (normative) Draining the oil from a refrigerating system		16
Annex B (informative) Guide specification (parameters) for recycled refrigerant		17
Annex C (informative) Handling and storage of refrigerants		18
Annex D (informative) In-service inspection		20
Annex E (informative) Guidelines for repairs of equipment using flammable refrigerants		22
Bibliography		25