

# DIN EN 15625:2010-05 (E)

## Railway applications - Braking - Automatic variable load sensing devices

---

<b>Contents</b>		<b>Page</b>
Foreword .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms, definitions and symbols .....</b>	<b>5</b>
3.1	Terms and definitions .....	5
3.2	Symbols .....	6
<b>4</b>	<b>Design and manufacture .....</b>	<b>6</b>
4.1	General .....	6
4.2	Functional requirements .....	7
4.2.1	Operating requirements .....	7
4.2.2	Characteristics of weighing valves .....	7
4.2.3	Mechanical requirements .....	9
4.2.4	Leakage .....	9
4.3	Vibrations and shock .....	9
4.4	Environment .....	10
4.4.1	General .....	10
4.4.2	Temperature .....	10
4.4.3	Other environmental conditions .....	10
4.5	Compressed air quality .....	12
4.6	Service life .....	12
4.7	Fire behaviour .....	13
4.8	External appearance .....	13
4.9	Design requirements regarding pressure stress .....	13
4.10	Interfaces .....	13
4.10.1	Mechanical .....	13
4.10.2	Pneumatic .....	13
<b>5</b>	<b>Materials .....</b>	<b>13</b>
<b>6</b>	<b>Type tests .....</b>	<b>13</b>
6.1	General .....	13
6.2	Individual automatic variable load sensing device type tests .....	14
6.2.1	Test bench for individual automatic variable load sensing devices type tests .....	14
6.2.2	Sampling for type test .....	15
6.2.3	Test requirements .....	15
6.2.4	Check of physical and geometrical characteristics .....	16
6.2.5	Leakage .....	16
6.2.6	Characteristic, hysteresis .....	17
6.2.7	Operation at extreme temperatures .....	18
6.2.8	Vibration and shock tests .....	20
<b>7</b>	<b>Routine tests (serial tests) and inspection .....</b>	<b>21</b>
7.1	General .....	21
7.2	Check of characteristic .....	21
7.2.1	Procedure .....	21
7.2.2	Pass/fail criteria .....	22
<b>8</b>	<b>Type validation .....</b>	<b>22</b>

<b>9</b>	<b>Documentation .....</b>	<b>22</b>
<b>10</b>	<b>Designation .....</b>	<b>22</b>
<b>11</b>	<b>Identification and marking .....</b>	<b>23</b>
<b>Annex A (informative) Assessment of an automatic variable load sensing device when fitted to a vehicle .....</b>		
		<b>24</b>
<b>A.1</b>	<b>Vehicle assessment - Testing set up .....</b>	<b>24</b>
<b>A.2</b>	<b>Design acceptance testing set up .....</b>	<b>24</b>
<b>A.3</b>	<b>Running tests .....</b>	<b>24</b>
<b>A.3.1</b>	<b>General .....</b>	<b>24</b>
<b>A.3.2</b>	<b>Pneumatic automatic variable load sensing device - Air consumption .....</b>	<b>24</b>
<b>A.3.3</b>	<b>Automatic variable load sensing device - Output signal variation .....</b>	<b>25</b>
<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 96/48/EC, as amended by Directive 2004/50/EC .....</b>		
		<b>26</b>
<b>Annex ZB (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2001/16/EC, as amended by EU Directive 2004/50/EC .....</b>		
		<b>27</b>
<b>Bibliography .....</b>		
		<b>28</b>