

# DIN EN 13231-1:2013-07 (E)

## Railway applications - Track - Acceptance of works - Part 1: Works on ballasted track - Plain line, switches and crossings

---

<b>Contents</b>		<b>Page</b>
Foreword .....		3
1	Scope .....	4
2	Normative references .....	4
3	Terms and definitions .....	4
4	Acceptance of works on plain line and on switches and crossings and rail expansion devices .....	6
4.1	General .....	6
4.2	Acceptance deadlines .....	6
4.3	Acceptance measurements, checks and related documentation .....	7
4.4	Relative track geometry .....	8
4.5	Absolute track position .....	11
4.6	Other parameters and verifications for plain line and switches and crossings .....	12
4.7	Specific measurements for switches and crossings and rail expansion devices .....	15
4.8	Specific quality checks for switches and crossings and rail expansion devices .....	16
5	Working parameters .....	17
5.1	General .....	17
5.2	Tamping working parameters .....	17
5.3	Dynamic stabilising working parameters .....	18
5.4	Ballast compaction working parameters .....	19
5.5	Ballast replacement/cleaning working parameters .....	19
6	Acceptance responsibilities .....	20
6.1	Preliminary procedure to acceptance .....	20
6.2	Consequences of the preliminary procedure to the acceptance .....	21
7	Warranty .....	21
Annex A (informative) Guidelines for specification of requirements of geodetic measurements .....		22
Annex B (informative) Switches and crossings measurements and checks .....		23
Bibliography .....		30