DIN EN 12397:2017-06 (E nglisch)

Safety requirements for cableway installations designed to carry persons - Operation

Contents

Page

European foreword 4

1 Scope 6

2 Normative references 6

3 Terms and definitions 6

4 General requirements 7
4.1 Application of this standard 7
4.2 Safety principles 7
4.2.1 General 7
4.2.2 Hazard factors 7
4.2.3 Safety measures 7
4.2.4 Safety of workers 8

5 Operating arrangements 9
5.1 Preliminary notes 9
5.2 Operating personnel and tasks 9
5.2.1 General 9
5.2.2 Tasks of the head of operation 9
5.2.3 Tasks of the operator 10
5.2.4 Tasks of the other operating personnel 11
5.2.5 Requirements for the operating personnel 11
5.3 Operation 11
5.3.1 Operation under normal conditions 11
5.3.2 Operation under exceptional circumstances 12
5.4 Operating checks 12
5.5 Operating disruptions 12
5.5.1 General 13
5.5.2 Abnormal situations and incidents 13
5.5.3 Prolonged stoppage 13
5.5.4 Accidents 13
5.6 Information and signage for passengers 13
5.7 Documents 13
5.8 Fire prevention and fire-fighting 14

6 Passenger arrangements 14
6.1 General 14
6.2 Terms of access and transportation 15
6.2.1 General 15
6.2.2 Disabled passengers 15
6.2.3 Ski and leisure equipment, luggage, miscellaneous items and animals 15
6.2.4 Exclusions 15
6.3 Passenger behaviour 15
6.3.1 General 15
6.3.2 Basic rules 16
6.3.3 Special rules 16
6.4 Accidents and incidents during operation 17

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2000/9/EC relating to cableway installations designed to carry persons 18