DIN EN 13129:2016-12 (E)

Railway applications - Air conditioning for main line rolling stock - Comfort parameters and type tests

Contents

Page

European foreword 5

1 Scope 6

2 Normative references 6

3 Terms and definitions 6

4 Compliance with the standard 12

5 Comfort parameters 13

6 Quality limits 13

7 Service conditions 14
7.1 Exterior conditions 14
7.1.1 Design conditions 14
7.1.2 Extreme conditions 15
7.2 Interior conditions 15

8 Performance of the heating and cooling installations 16
8.1 Preheating 16
8.2 Heating 16
8.3 Precooling 16
8.4 Cooling 16
8.5 Stand by operation 17
8.6 Door opening sequence 17
8.7 Degraded mode operation 17

9 Control 17
9.1 General 17
9.2 Interior temperature setting 17
9.3 Quality of regulation 18
9.3.1 General 18
9.3.2 Changing the interior temperature setting 18
9.3.3 Changing test parameter(s) 19
9.3.4 Stabilized conditions 20

10 Comfort conditions to be respected 22
10.1 Parameters in the comfort envelope 22
10.1.1 Temperatures in the comfort zones 22
10.1.2 Temperatures of the surfaces surrounding the comfort envelope 23
10.1.3 Humidity of the air 24
10.1.4 Air speed 25
10.1.5 Air quality 26
10.2 Parameters in the annex areas 28
10.3 Interior parameters in the catering service areas (galley zone) 29
10.4 Limits of temperature values 29

11 Supplementary requirements 30
11.1 Heat transfer coefficient 30

11.2 Solar factor (g) of the windows 30
11.3 Cleaning of air conditioning installation 30

12 Air movement tests 30
12.1 Air flow tests at standstill 30
12.1.1 Test conditions 30
12.1.2 Air flow rates 30
12.1.3 Visualization of the air flow direction 31
12.2 Air flow tests when driving 31
12.3 Air speed tests 31
12.3.1 Critical air speed 31
12.3.2 Measurement of air speed during the climatic tests 31

13 Climatic tests 31
13.1 General remarks 31
13.2 Preheating test 32
13.3 Precooling test 32
13.4 Regulation tests 32
13.4.1 Steady-state tests 32
13.4.2 Intermediate tests 33
13.4.3 Tests for typical daily profiles 33
13.5 Functionality tests 33

14 Supplementary tests 34
14.1 Determination of the heat transfer coefficient 34
14.1.1 Purpose of the test 34
14.1.2 Calculation 34
14.1.3 Procedure 34
14.2 Thermography 35

15 Methods of measurement - Measuring instruments 35
15.1 General remarks 35
15.2 Temperatures 35
15.2.1 Air temperature 35
15.2.2 Surface temperatures 35
15.3 Relative humidity 35
15.4 Air speed 35
15.5 Airflow rate 35
15.6 Simulated speed of the vehicle 35
15.7 Equivalent solar energy 36
15.8 Energy consumption and power rating 36

16 Characteristics of the test equipment 36
16.1 General remarks 36
16.2 Occupation 36
16.3 Temperature and uniformity of the climatic chamber 36
16.4 Relative humidity 36
16.5 Simulation of wind speed 36
16.6 Equivalent solar energy 37

17 Distribution of measuring points 37
17.1 Distribution of sensors in the vehicle 37
17.1.1 Comfort envelope temperature measuring points 37
17.1.2 Surface temperature measuring points 37
17.1.3 Supply air outlet temperature measuring points 38
17.1.4 Comfort envelope air speed measuring points 38
17.1.5 Comfort envelope relative humidity measuring points 38
17.2 Climatic chamber sensors distribution 38

Annex A (informative) Grouping of countries in climatic zones 39

Annex B (normative) Calculation method of the overall conformity level CL 40

Annex C (normative) Tests for verification of comfort parameters 43

Annex D (normative) Equivalent solar energy (Simulation of solar exposure) 53

Annex E (normative) Location of the measuring points used for the determination of the mean interior temperature in the comfort envelope (Tim), horizontal range of the extreme interior air temperatures and the measuring point location in the local annexes 54

Annex F (normative) Location of the measuring points used for the determination of the vertical ranges of the extreme interior air temperatures and relative humidity across the comfort envelope 56

Annex G (normative) Location of the measuring points used for the determination of the variation of internal temperatures within the comfort envelope 58

Annex H (informative) Location of the sensors in the climatic chamber 60

Annex I (normative) Typical daily profiles 61

Annex J (normative) Heat emission per person 73

Annex K (informative) Abbreviations 75

K.1 Surface temperatures: TS__Range_Surface concerned 75
K.2 Airflow: V_Type of airflo 75
K.3 Range of temperature: T_Mode_Location 75
K.4 Gradients: T Type of gradient_Range_Location 76
K.5 Others 76

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2008/57/EC 77

Bibliography 79